

Motion Controller

PMC-2HSP/2HSN

Library Manual



Preface

Thank you very much for selecting Autonics products.

Please familiarize yourself with the information contained in the Safety Precautions section before using this product.

This user manual contains information about the product and its proper use, and should be kept in a place where it will be easy to access.

Library Manual Guide

- This user manual contains information about the product and its proper use, and should be kept in a place where it will be easy to access.
- Familiarize yourself with the information in this manual before using the product.
- This manual provides detailed information on the product's library. It does not offer any guarantee concerning matters beyond the scope of this manual.
- This manual may not be edited or reproduced in either part or whole without permission.
- A user manual is provided as part of the product package. Visit our home-page (www.autonics.com) to download a copy.
- The manual's content may vary depending on changes to the product's software and other unforeseen developments within Autonics, and is subject to change without prior notice.
- We contrived to describe this manual more easily and correctly. However, if there are any corrections or questions, please notify us these on our homepage.
- This manual provides usage examples of each function and program's examples of MFC-based which is utilized functions .

Library Manual Symbols

Symbol	Description
 Note	Supplementary information for a particular feature.
 Warning	Failure to follow instructions can result in serious injury or death.
 Caution	Failure to follow instructions can lead to a minor injury or product damage.
 Ex.	An example of the concerned feature's use.
※1	Annotation mark.

Safety Considerations

- Please observe all safety considerations for safe and proper product operation to avoid hazards.
- Safety considerations are categorized as follows.

 Warning	Warning	Failure to follow these instructions may result in serious injury or death.
--	----------------	---

 Caution	Caution	Failure to follow these instructions may result in personal injury or product damage.
--	----------------	---

Warning

- Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.)
Failure to follow this instruction may result in personal injury, fire, or economic loss.
- Familiarize yourself with the information in this manual before using or installing the product. Failure to follow this instruction may result in mechanical losses, personal injury, or malfunction by operation mistakes.
- Do not use the unit where flammable or explosive gas, corrosive material, or direct ray of sun may be present. Failure to follow this instruction may result in electric shock, fire, personal injury, or economic loss.
- Install an emergency switch, or limit switch at the dangerous point before installing the unit. Failure to follow this instruction may result in personal injury, or economic loss.
- Install the unit after considering counter plan against power failure. Failure to follow this instruction may result in personal injury, or economic loss.
- Do not insert any objects such as materials at the openings of the unit. Failure to follow this instruction may result in fire, electric shock.
- Power supply should be rectified power by using insulation trans. Failure to follow this instruction may result in fire, electric shock, or personal injury.
- Check the rated power input specifications before supplying the power. Failure to follow this instruction may result in fire.
- Do not connect, maintain, or repair the unit when power is supplied to the unit. Failure to follow this instruction may result in electric shock, product damage, or malfunction.
- Do not turn off the power or remove the connector during operation. Failure to follow this instruction may result in personal injury or economic loss.
- Do not disassemble or modify the unit..Failure to follow this instruction may result in electric shock, or fire .

Caution

- Tighten the the power and signal cables on the unit firmly. Failure to follow this instruction may result in electric shock, or product damage.

- Tighten the screws between the power connector and the RS485 connector with max. 0.4N·m torque. Failure to follow this instruction may result in screw damage and poor contact.
- Use AWG28-16 cables for power cable. Failure to follow this instruction may result in fire.
- When using ribbon cable to I/O cable, connect the cable properly without poor connection by ribbon cable. Failure to follow this instruction may result in malfunction.
- Check the specifications and type of connector before connecting the unit. Failure to follow this instruction may result in fire, electric shock, or product damage.
- Use the unit within the rated specifications. Failure to follow this instruction may result in shorten the life cycle of the unit, or fire.
- Separate cables not to impact the noise from power, or load cables. Failure to follow this instruction may result in malfunction, or product damage.
- Do not use water or oil-based detergent when cleaning the unit. Failure to follow this instruction may result in electric shock, fire, or product damage.
- When disposing the unit, please categorize it as industrial waste.
- Note that this device is KC certified for commercial use. Make proper applications for the product.

Table of Contents

1	Reset	12
1.1	autpmc_Open	12
1.2	autpmc_Reset.....	14
1.3	autpmc_IsCon.....	15
1.4	autpmc_SetBaudrate.....	17
1.5	autpmc_ClrINCPos.....	19
1.6	autpmc_Timeout.....	21
2	Stop, End	24
2.1	autpmc_Close.....	24
2.2	autpmc_SlowStop.....	25
2.3	autpmc_EmgStop	27
3	Parameter Setting	28
3.1	autpmc_GetParaAll.....	28
3.2	autpmc_GetParaOPMAIL	33
3.3	autpmc_GetParaPMAIL	36
3.4	autpmc_GetParaHSMAIL	39
3.5	autpmc_GetLmtStopMod.....	42
3.6	autpmc_GetLmtActLev	44
3.7	autpmc_GetSCurve	46
3.8	autpmc_GetEndPEnable	48
3.9	autpmc_GetDecValue.....	50
3.10	autpmc_GetSofLmtEnable	52
3.11	autpmc_GetPowHomStart	54
3.12	autpmc_GetPowPgmStart	56
3.13	autpmc_GetInputLev	58
3.14	autpmc_GetPulseType	60
3.15	autpmc_GetSpdMul	62
3.16	autpmc_GetJrkSpd	64
3.17	autpmc_GetAccSpdRate	66
3.18	autpmc_GetDecSpdRate.....	68
3.19	autpmc_GetStrSpd	70
3.20	autpmc_GetCurDrvSpd	72
3.21	autpmc_GetDrvSpdPgm.....	74
3.22	autpmc_GetTimPgm.....	76
3.23	autpmc_GetSofLmt.....	78
3.24	autpmc_GetEndPWidth	80
3.25	autpmc_GetPulSciNum	82
3.26	autpmc_GetPulSciDen	84
3.27	autpmc_GetHomMod	86

3.28	autpmc_GetHomEndPosClr	88
3.29	autpmc_GetHomSigLev.....	90
3.30	autpmc_GetHomSpd	92
3.31	autpmc_GetHomOffset	94
3.32	autpmc_SetLmtStopMod	96
3.33	autpmc_SetLmtActLev.....	98
3.34	autpmc_SetSCurve.....	100
3.35	autpmc_SetEndPEnable	102
3.36	autpmc_SetDecValue	104
3.37	autpmc_SetSofLmtEnable.....	106
3.38	autpmc_SetPowHomStart.....	108
3.39	autpmc_SetPowPgmStart.....	110
3.40	autpmc_SetInputLev.....	112
3.41	autpmc_SetPulseType.....	114
3.42	autpmc_SetSpdMul.....	115
3.43	autpmc_SetJrkSpd.....	117
3.44	autpmc_SetAccSpdRate.....	119
3.45	autpmc_SetDecSpdRate	121
3.46	autpmc_SetStrSpd	123
3.47	autpmc_SetDrvSpd.....	125
3.48	autpmc_SetDrvSpdPgm	127
3.49	autpmc_SetTimPgm	129
3.50	autpmc_SetSofLmt	131
3.51	autpmc_SetEndPWidth.....	133
3.52	autpmc_SetPulSciNum.....	135
3.53	autpmc_SetPulSciDen.....	137
3.54	autpmc_SetHomMod	139
3.55	autpmc_HomStop	141
3.56	autpmc_Step1Enable.....	143
3.57	autpmc_Step2Enable.....	145
3.58	autpmc_Step3Enable.....	147
3.59	autpmc_Step4Enable.....	149
3.60	autpmc_Step1Direction.....	151
3.61	autpmc_Step2Direction.....	153
3.62	autpmc_Step3Direction.....	155
3.63	autpmc_Step4Direction.....	157
3.64	autpmc_SetHomEndPosClr.....	159
3.65	autpmc_SetHomSigLev	161
3.66	autpmc_SetHomSpd.....	163
3.67	autpmc_SetHomOffset	165
4	I/O Control	168
4.1	autpmc_GetParallelIO	168

4.2	autpmc_GetAxisIO.....	170
4.3	autpmc_SetUserOut.....	172
4.4	autpmc_GetCurPos.....	174
4.5	autpmc_GetCurPgmNo.....	176
4.6	autpmc_GetErrorSt.....	178
4.7	autpmc_IsRun.....	180
4.8	autpmc_GetModName.....	182
4.9	autpmc_GetSofVer.....	184
5	Movement.....	186
5.1	autpmc_HomRun.....	186
5.2	autpmc_ABSMove.....	188
5.3	autpmc_INCMove.....	190
5.4	autpmc_ContMove.....	192
5.5	autpmc_LIDMove.....	194
5.6	autpmc_CIDMove.....	196
5.7	autpmc_FIDMove.....	198
5.8	autpmc_RIDMove.....	200
6	Program Control.....	202
6.1	autpmc_PgmRun.....	202
6.2	autpmc_PgmStepRun.....	204
6.3	autpmc_PgmPause.....	206
6.4	autpmc_PgmReRun.....	208
6.5	autpmc_PgmStop.....	210
6.6	autpmc_DelPgmData.....	212
6.7	autpmc_DelPgmDataAll.....	214
6.8	autpmc_PgmABS.....	216
6.9	autpmc_PgmINC.....	218
6.10	autpmc_PgmHOM.....	220
6.11	autpmc_PgmLID.....	222
6.12	autpmc_PgmCID.....	224
6.13	autpmc_PgmFID.....	226
6.14	autpmc_PgmRID.....	228
6.15	autpmc_PgmICJ.....	230
6.16	autpmc_PgmIRD.....	232
6.17	autpmc_PgmOPC.....	234
6.18	autpmc_PgmOPT.....	236
6.19	autpmc_PgmJMP.....	238
6.20	autpmc_PgmREP.....	240
6.21	autpmc_PgmRPE.....	242
6.22	autpmc_PgmEND.....	244
6.23	autpmc_PgmTIM.....	246
6.24	autpmc_PgmNOP.....	248

7 Example Of MFC Program For Using Library250

※For more detailed function and terms, refer to PMC-2HSP/PMC-2HSN user manual. Visit our website (www.autonics.com) to download it.

1 Reset

1.1 autpmc_Open

This function, autpmc_Open, is for connecting to PMC-2HSP/2HSN for communication.

(1) Syntax

```
int autpmc_Open(
  int PortNum,
  int BaudRate
);
```

(2) Parameter

- PortNum
Enter serial port number to be connected.
- BaudRate
Enter baudrate of serial port.

Item	Input	Description	Constant value
PMC_BAUDRATE	FPMC_BAUD_9600	9,600bps	9600
	FPMC_BAUD_19200	19,200bps	19200
	FPMC_BAUD_38400	38,400bps	38400
	FPMC_BAUD_57600	57,600bps	57600
	FPMC_BAUD_115200	115,200bps	115200

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_PORT	1	Unavailable or invalid input port is entered.
	FPMC_INVALID_BAUDRATE	2	Invalid baudrate is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define COMPORT 15

void main()
{

  int stat=0;
  int i;

  // Communication connection function of PMC-2HSP(N)
  // Return value : Returns FPMC_OK when executing the command normally.
  // Factor value: Serial port number, Serial port baudrate to be connected.
  // stat : Checks the status of connectable comport.

  for(i=0;i<COMPORT;i++)
  {
```

```
switch(i)
{
case 0: stat = autpmc_Open( 0, FPMC_BAUD_115200 );
        break;
case 1: stat = autpmc_Open( 1, FPMC_BAUD_115200 );
        break;
case 2: stat = autpmc_Open( 2, FPMC_BAUD_115200 );
        break;
case 3: stat = autpmc_Open( 3, FPMC_BAUD_115200 );
        break;
case 4: stat = autpmc_Open( 4, FPMC_BAUD_115200 );
        break;
case 5: stat = autpmc_Open( 5, FPMC_BAUD_115200 );
        break;
case 6: stat = autpmc_Open( 6, FPMC_BAUD_115200 );
        break;
case 7: stat = autpmc_Open( 7, FPMC_BAUD_115200 );
        break;
case 8: stat = autpmc_Open( 8, FPMC_BAUD_115200 );
        break;
case 9: stat = autpmc_Open( 9, FPMC_BAUD_115200 );
        break;
case 10: stat = autpmc_Open(10, FPMC_BAUD_115200);
        break;
case 11: stat = autpmc_Open(11, FPMC_BAUD_115200);
        break;
case 12: stat = autpmc_Open(12, FPMC_BAUD_115200);
        break;
case 13: stat = autpmc_Open(13, FPMC_BAUD_115200);
        break;
case 14: stat = autpmc_Open(14, FPMC_BAUD_115200);
        break;
case 15: stat = autpmc_Open(15, FPMC_BAUD_115200);
        break;
}

if (stat == FPMC_OK)
{
    printf("MESSAGE : Found and open 'PMC-2HSP(N) (ID=%d)'
ComPort\n", i);
}
}
}
```

1.2 autpmc_Reset

This function, autpmc_Reset, is for resetting motion IC by broadcast of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Reset(
  int PortNum,
  char nNodeID
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range. Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM      3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  Flag = autpmc_Reset (PORTNUM, Node01);

  if(Flag!=FPMC_OK)
  {
    printf("error!\n");
    return;
  }

  autpmc_Close(PORTNUM);
}
```

1.3 autpmc_IsCon

This function, `autpmc_IsCon`, is for checking normally transferring data by communicating PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_IsCon(
int PortNum,
char nNodeId,
BOOL *bOn
);
```

(2) Parameter

- **PortNum**
Enter serial port number to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **bOn**
When command is successful, 1 is saved at data . When command is fail, 0 is saved at data .

(3) Return value

Item	Definition	Return value	Description
Normal	<code>FPMC_OK</code>	0	The command is normally executed.
Input error	<code>FPMC_INVALID_NODE</code>	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM      3

void main()
{
int Flag=0; //Checking the operation status of the function.

BOOL bOn=0; //Unit connection (connection ON(1), connection OFF(0))

autpmc_Open(PORTNUM, FPMC_BAUD_115200); //Communication connection function

//Function of checking connection PMC-2HSP(N)
//Return value : Returns FPMC_OK when executing the command normally.
//Factor : Status of setting node ID, unit connection: connection ON(1), connection OFF(0)

Flag = autpmc_IsCon(PORTNUM, Node01, &bOn);

printf("%d\n", bOn);

if (bOn == 1)
{
printf("Connection!\n");
```

```
}  
else  
{  
    printf("Connection Failed\n");  
}  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

1.4 autpmc_SetBaudrate

This function, `autpmc_SetBaudrate`, is for changing baudrate of PMC-2HSP/2HSN by broadcast function.

(1) Syntax

```
int autpmc_SetBaudrate(
    int PortNum,
    char nNodeID,
    int BaudRate
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeID**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range. Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.
- **BaudRate**
Enter baudrate to be changed.

Item	Input	Description	Constant value
PMC_BAUDRATE	FPMC_BAUD_9600	9,600bps	9600
	FPMC_BAUD_19200	19,200bps	19200
	FPMC_BAUD_38400	38,400bps	38400
	FPMC_BAUD_57600	57,600bps	57600
	FPMC_BAUD_115200	115,200bps	115200

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_BAUDRATE	2	Invalid baudrate is entered.
	FPMC_INVALID_NODE	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM      3

void main()
{

    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_SetBaudrate(PORTNUM, Node01, FPMC_BAUD_9600);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

1.5 autpmc_ClrINCPos

This function, `autpmc_ClrINCPos`, is for resetting the relative position of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_ClrINCPos(
int PortNum,
char nNodeId,
char axis
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_ClrINCPos(PORTNUM, Node01, FPMC_X_Y_AXIS);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }
}
```

```
}
```

```
autpmc_Close(PORTNUM);  
}
```

1.6 autpmc_Timeout

This function, `autpmc_Timeout`, is for setting wait time of send/receive command of PMC-2HSP/2HSN. If there is no settings when loading the port value, it waits unlimitedly until all commands are received at the designated receive buffer. Set this function for setting wait time of the receive operation after period of time.

(1) Syntax

```
int autpmc_Timeout(
    int PortNum,
    int RTimeout,
    int RTTimeoutMultiplier,
    int RTTimeoutConstant,
    int WTimeoutMultiplier,
    int WTimeoutConstant
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **RTimeout(ReadIntervalTimeout)**
Read interval timeout is for setting the response time between byte and byte. If the next byte does not response within the set time, timeout occurs.
Max. time interval between responded 2 byte is set by ms unit.
During read operation, the first byte is received and interval timeout starts. If 1 byte is received and next 1 byte is not received after read interval timeout, read operation is complete.
Enter 0 not to set read interval timeout.
- **RTTimeoutMultiplier(ReadTotalTimeoutMultiplier)**
Read total timeout multiplier is for setting read timeout value per byte and constant value by ms unit.
- **RTTimeoutConstant(ReadTotalTimeoutConstant)**
Read total timeout constant is constant value for calculating total read timeout interval by ms unit.
During each read operation, multiply the value to `ReadTotalTimeoutMultiplier` and add the value to the number of read byte.
If the number of read byte is 'n', calculate read timeout value as below formular.
$$\text{Read timeout(ms)} = n \times \text{ReadTotalTimeoutMultiplier} + \text{ReadTotalTimeoutConstant}$$

Enter 0 for `ReadTotalTimeoutMultiplier` and `ReadTotalTimeoutConstant` not to use read timeout.
- **WTimeoutMultiplier(WriteTotalTimeoutMultiplier)**
Write total timeout multiplier is for setting multiplication factor to calculate total timeout for write operation by ms unit.
- **WTimeoutConstant(WriteTotalTimeoutConstant)**
Write total timeout constant is for using constant to calculate total timeout for write operation by ms unit.
If the number of the sent byte, calculate write timeout value as below formular.

Write timeout(ms) = $n \times \text{WriteTotalTimeoutMultiplier} + \text{WriteTotalTimeoutConstant}$

Enter 0 for WriteTotalTimeoutMultiplier and WriteTotalTimeoutConstant not to use write time.

※ Set the appropriate timeout. If not, it takes too much time for reading data, or the unit cannot read data due to too short timeout.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_PORT	1	Unavailable port

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0; // Checks the operation status of the function.

    autpmc_Open(PORTNUM, FPMC_BAUD_115200); //Communication connection function

    Flag = autpmc_Timeout(PORTNUM, 0, 1, 1, 0, 0); //Changes wait time of send/receive
    command

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM); //Disconnect communication
}
```


2 Stop, End

2.1 autpmc_Close

This function, autpmc_Close, is for disconnecting communication of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Close(PORTNUM);
```

(2) Parameter

None

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_PORT	1	Unavailable port

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{

    int Flag=0; // Checks the operation status of the function.

    Flag = autpmc_Open(PORTNUM, FPMC_BAUD_115200); //Communication connection
function

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM); //Disconnect communication.
}
```

2.2 autpmc_SlowStop

This function, autpmc_SlowStop, is for decelerating to stop PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SlowStop(
int PortNum,
char nNodeId,
char axis
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{

int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SlowStop(PORTNUM, Node01, FPMC_X_Y_AXIS);

if(Flag!=FPMC_OK)
{
printf("error!\n");
return;
}
```

```
}
```

```
autpmc_Close(PORTNUM);  
}
```

2.3 autpmc_EmgStop

This function, autpmc_EmgStop, is for stopping PMC-2HSP/2HSN emergently by broadcast function.

(1) Syntax

```
int autpmc_EmgStop(
int PortNum,
char nNodeId
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_EmgStop(PORTNUM, Broadcast);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

3 Parameter Setting

3.1 autpmc_GetParaAll

This function, autpmc_GetParaAll, is for loading all setting values of PMC-2HSP/2HSN.

(1) Syntax

```
struct PMC_PARADATA *autpmc_GetParaAll(
  int PortNum,
  char nNodeID,
  char axis,
  PMC_PARADATA *pData
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- pData
Loads and saves all parameters' information once.

Structure name	Variable format	Description	Data value
PMC_PARADATA	int iErrorState	Check error status.	0 : The command is normally executed. 3 : Invalid node ID is entered. 4 : Invalid axis is entered. 5 : Invalid data is entered.
	BOOL bLmtStopMod[2]	Instant/Slow limit stop mode (X-axis : bLmtStopMod[0], Y-axis : bLmtStopMod[1])	0 : Instant 1 : Slow
	BOOL bLmtActLev[2]	Limit signal logic level low/high (X-axis : bLmtActLev [0], Y-axis : bLmtActLev [1])	0 : Low 1 : High
	BOOL bSCurve[2]	Enable/Disable S-curve acceleration/deceleration (X-axis : bSCurve [0], Y-axis : bSCurve [1])	0 : Disable 1 : Enable
	BOOL bEndPEnable[2]	Enable/Disable of drive end pulse (X-axis : bEndPEnable [0], Y-axis : bEndPEnable [1])	0 : Disable 1 : Enable

Structure name	Variable format	Description	Data value
	BOOL bDecValue[2]	Symmetry/Asymmetry of trapezoidal acceleration/deceleration drive (X-axis : bDecValue [0], Y-axis : bDecValue [1])	0 : Accel 1 : Decel
	BOOL bSofLmtEnable[2]	Enable/Disable of software limit (X-axis : bSofLmtEnable [0], Y-axis : bSofLmtEnable [1])	0 : Enable 1 : Disable
	BOOL bPowHomStart[2]	Enable/Disable automatic start of power-on home search (X-axis : bPowHomStart [0], Y-axis : bPowHomStart [1])	0 : Disable 1 : Enable
	BOOL bPowPgmStart[2]	Enable/Disable automatic start of power-on program (X-axis : bPowPgmStart [0], Y-axis : bPowPgmStart [1])	0 : Disable 1 : Enable
	BOOL bInput0Lev[2]	Active level low/high of general input 0 (X-axis : bInput0Lev [0], Y-axis : bInput0Lev [1])	0 : Low 1 : High
	BOOL bInput1Lev[2]	Active level low/high of general input 1 (X-axis : bInput1Lev [0], Y-axis : bInput1Lev [1])	0 : Low 1 : High
	int iPulseType	Pulse input method: 1PULSE, 2PULSE	1 : 1PULSE 2 : 2PULSE
	int iSpdMul[2]	Speed multiplier (X-axis : iSpdMul [0], Y-axis : iSpdMul [1])	1 to 500
	int iJrkSpd[2]	Jerk speed (X-axis : iJrkSpd [0], Y-axis : iJrkSpd [1])	1 to 65535
	int iAccSpdRate[2]	Acceleration rate (X-axis : iAccSpdRate [0], Y-axis : iAccSpdRate [1])	1 to 8000
	int iDecSpdRate[2]	Deceleration rate (X-axis : iDecSpdRate [0], Y-axis : iDecSpdRate [1])	1 to 8000
	int iStrSpd[2]	Start speed (X-axis : iStrSpd [0], Y-axis : iStrSpd [1])	1 to 8000
	int iDrvSpd[2]	Drive speed (X-axis : iDrvSpd [0], Y-axis : iDrvSpd [1])	1 to 8000
	int iDrvSpd1Pgm[2]	Drive speed 1 using at program mode (X-axis : iDrvSpd1Pgm [0], Y-axis : iDrvSpd1Pgm [1])	1 to 8000
	int iDrvSpd2Pgm[2]	Drive speed 2 using at program mode (X-axis : iDrvSpd2Pgm [0], Y-axis : iDrvSpd2Pgm [1])	1 to 8000
	int iDrvSpd3Pgm[2]	Drive speed 3 using at program mode (X-axis : iDrvSpd3Pgm [0], Y-axis : iDrvSpd3Pgm [1])	1 to 8000
	int iDrvSpd4Pgm[2]	Drive speed 4 using at program mode (X-axis : iDrvSpd4Pgm [0], Y-axis : iDrvSpd4Pgm [1])	1 to 8000
	int iTim1Pgm[2]	Post-timer 1 using at program	1 to 65535

Structure name	Variable format	Description	Data value
		mode (X-axis : iTim1Pgm [0], Y-axis : iTim1Pgm [1])	
	int iTim2Pgm[2]	Post-timer 2 using at program mode (X-axis : iTim2Pgm [0], Y-axis : iTim2Pgm [1])	1 to 65535
	int iTim3Pgm[2]	Post-timer 3 using at program mode (X-axis : iTim3Pgm [0], Y-axis : iTim3Pgm [1])	1 to 65535
	long ISofLmtP[2]	+ direction software limit (X-axis : ISofLmtP [0], Y-axis : ISofLmtP [1])	-8388608 to 8388607
	long ISofLmtM[2]	- direction software limit (X-axis : ISofLmtM [0], Y-axis : ISofLmtM [1])	- 8388608 to 8388607
	int iEndPWidth[2]	Drive end pulse width (X-axis : iEndPWidth [0], Y-axis : iEndPWidth [1])	1 to 65535
	int iPulScINum[2]	Numerator of pulse scale (X-axis : iPulScINum [0], Y-axis : iPulScINum [1])	1 to 65535
	int iPulScIDen[2]	Denominator of pulse scale (X-axis : iPulScIDen [0], Y-axis : iPulScIDen [1])	1 to 65535
	BOOL bHomMod1[2]	Enable/Disable step 1 of home search mode (X-axis : bHomMod1 [0], Y-axis : bHomMod1 [1])	0 : Disable 1 : Enable
	BOOL bHomMod1Dir[2]	Step 1 search direction of home search mode (X-axis : bHomMod1Dir [0], Y-axis : bHomMod1Dir [1])	0 : + direction 1 : - direction
	BOOL bHomMod2[2]	Enable/Disable step 2 of home search mode (X-axis : bHomMod2 [0], Y-axis : bHomMod2 [1])	0 : Disable 1 : Enable
	BOOL bHomMod2Dir[2]	Step 2 search direction of home search mode (X-axis : bHomMod2Dir [0], Y-axis : bHomMod2Dir [1])	0 : + direction 1 : - direction
	BOOL bHomMod3[2]	Enable/Disable step 3 of home search mode (X-axis : bHomMod3 [0], Y-axis : bHomMod3 [1])	0 : Disable 1 : Enable
	BOOL bHomMod3Dir[2]	Step 3 search direction of home search mode (X-axis : bHomMod3Dir [0], Y-axis : bHomMod3Dir [1])	0 : + direction 1 : - direction
	BOOL bHomMod4[2]	Enable/Disable step 4 of home search mode (X-axis : bHomMod4 [0], Y-axis : bHomMod4 [1])	0 : Disable 1 : Enable
	BOOL bHomMod4Dir[2]	Step 4 search direction of home search mode (X-axis : bHomMod4Dir [0], Y-axis : bHomMod4Dir [1])	0 : + direction 1 : - direction

Structure name	Variable format	Description	Data value
	BOOL bHomEndPosClr[2]	Enable/Disable reset of position counter (X-axis : bHomEndPosClr [0], Y-axis : bHomEndPosClr [1])	0 : Disable 1 : Enable
	BOOL bHomSig0Lev[2]	Logic level low/high of near home signal(STOP 0) (X-axis : bHomSig0Lev [0], Y-axis : bHomSig0Lev [1])	0 : Low 1 : High
	BOOL bHomSig1Lev[2]	Logic level low/high of home signal(STOP1) (X-axis : bHomSig1Lev [0], Y-axis : bHomSig1Lev [1])	0 : Low 1 : High
	BOOL bHomSig2Lev[2]	Logic level low/high of encoder Z-phase signal(STOP2) (X-axis : bHomSig2Lev [0], Y-axis : bHomSig2Lev [1])	0 : Low 1 : High
	int iHomLowSpd[2]	Home search low speed (X-axis : iHomLowSpd [0], Y-axis : iHomLowSpd [1])	1 to 8000
	int iHomHighSpd[2]	Home search high speed (X-axis : iHomHighSpd [0], Y-axis : iHomHighSpd [1])	1 to 8000
	long lHomOffset[2]	High speed offset position of home search step 4 (X-axis : lHomOffset [0], Y-axis : lHomOffset [1])	0~8388607

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
PMC_PARADATA Data; // Defining structure variable
PMC_PARADATA *pData = &Data;

autpmc_GetParaAll(PORTNUM, Node01, FPMC_X_Y_AXIS, pData);

printf("X-axis Limit Stop Mode : %d\nY-axis Limit Stop Mode : %d\n", pData-
>bLmtStopMod[0], pData->bLmtStopMod[1]);

if(pData->iErrorState!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.2 autpmc_GetParaOPMAII

This function, `autpmc_GetParaOPMAII`, is for loading the setting value of operation mode of PMC-2HSP/2HSN.

(1) Syntax

```
struct PMC_PARADATA *autpmc_GetParaOPMAII(
    int PortNum,
    char nNodeID,
    char axis,
    PMC_PARADATA *pData
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeID**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **pData**
Loads and saves the related parameters of operation mode once.

Structure name	Variable format	Description	Data value
PMC_PARADATA	int iErrorState	Check error status.	0 : The command is normally executed. 3 : Invalid node ID is entered. 4 : Invalid axis is entered. 5 : Invalid data is entered.
	BOOL bLmtStopMod[2]	Limit stop mode Instant stop/Slow stop (X-axis : bLmtStopMod[0], Y-axis : bLmtStopMod[1])	0 : Instant 1 : Slow
	BOOL bLmtActLev[2]	Limit signal logic level low/high (X-axis : bLmtActLev [0], Y-axis : bLmtActLev [1])	0 : Low 1 : High
	BOOL bSCurve[2]	Enable/Disable S-curve acceleration/deceleration (X-axis : bSCurve [0], Y-axis : bSCurve [1])	0 : Disable 1 : Enable
	BOOL bEndPEnable[2]	Enable/Disable of drive end pulse (X-axis : bEndPEnable [0], Y-axis : bEndPEnable [1])	0 : Disable 1 : Enable

Structure name	Variable format	Description	Data value
	BOOL bDecValue[2]	Symmetry/Asymmetry of trapezoidal acceleration/deceleration drive (X-axis : bDecValue [0], Y-axis : bDecValue [1])	0 : Accel 1 : Decel
	BOOL bSofLmtEnable[2]	Enable/Disable of software limit (X-axis : bSofLmtEnable [0], Y-axis : bSofLmtEnable [1])	0 : Enable 1 : Disable
	BOOL bPowHomStart[2]	Enable/Disable automatic start of power-on home search (X-axis : bPowHomStart [0], Y-axis : bPowHomStart [1])	0 : Disable 1 : Enable
	BOOL bPowPgmStart[2]	Enable/Disable automatic start of power-on program (X-axis : bPowPgmStart [0], Y-axis : bPowPgmStart [1])	0 : Disable 1 : Enable
	BOOL bInput0Lev[2]	Active level low/high of general input 0 (X-axis : bInput0Lev [0], Y-axis : bInput0Lev [1])	0 : Low 1 : High
	BOOL bInput1Lev[2]	Active level low/high of general input 1 (X-axis : bInput1Lev [0], Y-axis : bInput1Lev [1])	0 : Low 1 : High

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    PMC_PARADATA Data; //Defining structure variable
    PMC_PARADATA *pData = &Data;

    autpmc_GetParaOPMAIL (PORTNUM, Node01, FPMC_X_Y_AXIS, pData);

    printf(" X-axis Limit Stop Mode : %d\n Y-axis Limit Stop Mode : %d\n", pData->bLmtStopMod[0], pData->bLmtStopMod[1]);

    if(pData->iErrorState!=FPMC_OK)
```

```
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.3 autpmc_GetParaPMail

This function, autpmc_GetParaPMail, is for loading the setting value of parameters of PMC-2HSP/2HSN.

(1) Syntax

```
struct PMC_PARADATA *autpmc_GetParaPMail(
  int PortNum,
  char nNodeId,
  char axis,
  PMC_PARADATA *pData
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ pData

Loads and saves all information of parameters once.

Structure name	Variable format	Description	Data value
PMC_PARADATA	int iErrorState	Check error status.	0 : The command is normally executed. 3 : Invalid node ID is entered. 4 : Invalid axis is entered. 5 : Invalid data is entered.
	int iPulseType	Pulse input method: 1PULSE, 2PULSE	1 : 1PULSE 2 : 2PULSE
	int iSpdMul[2]	Speed multiplier (X-axis : iSpdMul [0], Y-axis : iSpdMul [1])	1 to 500
	int iJrkSpd[2]	Jerk speed (X-axis : iJrkSpd [0], Y-axis : iJrkSpd [1])	1 to 65535
	int iAccSpdRate[2]	Acceleration rate (X-axis : iAccSpdRate [0], Y-axis : iAccSpdRate [1])	1 to 8000
	int iDecSpdRate[2]	Deceleration rate (X-axis : iDecSpdRate [0], Y-axis : iDecSpdRate [1])	1 to 8000
	int iStrSpd[2]	Start speed (X-axis : iStrSpd [0], Y-axis : iStrSpd [1])	1 to 8000

Structure name	Variable format	Description	Data value
	int iDrvSpd[2]	Drive speed (X-axis : iDrvSpd [0], Y-axis : iDrvSpd [1])	1 to 8000
	int iDrvSpd1Pgm[2]	Drive speed 1 using at program mode (X-axis : iDrvSpd1Pgm [0], Y-axis : iDrvSpd1Pgm [1])	1 to 8000
	int iDrvSpd2Pgm[2]	Drive speed 2 using at program mode (X-axis : iDrvSpd2Pgm [0], Y-axis : iDrvSpd2Pgm [1])	1 to 8000
	int iDrvSpd3Pgm[2]	Drive speed 3 using at program mode (X-axis : iDrvSpd3Pgm [0], Y-axis : iDrvSpd3Pgm [1])	1 to 8000
	int iDrvSpd4Pgm[2]	Drive speed 4 using at program mode (X-axis : iDrvSpd4Pgm [0], Y-axis : iDrvSpd4Pgm [1])	1 to 8000
	int iTim1Pgm[2]	Post-timer 1 using at program mode (X-axis : iTim1Pgm [0], Y-axis : iTim1Pgm [1])	1 to 65535
	int iTim2Pgm[2]	Post-timer 2 using at program mode (X-axis : iTim2Pgm [0], Y-axis : iTim2Pgm [1])	1 to 65535
	int iTim3Pgm[2]	Post-timer 3 using at program mode (X-axis : iTim3Pgm [0], Y-axis : iTim3Pgm [1])	1 to 65535
	long ISofLmtP[2]	+ direction software limit (X-axis : ISofLmtP [0], Y-axis : ISofLmtP [1])	-8388608 to 8388607
	long ISofLmtM[2]	- direction software limit (X-axis : ISofLmtM [0], Y-axis : ISofLmtM [1])	-8388608 to 8388607
	int iEndPWidth[2]	Drive end pulse width (X-axis : iEndPWidth [0], Y-axis : iEndPWidth [1])	1 to 65535
	int iPulSciNum[2]	Numerator of pulse scale (X-axis : iPulSciNum [0], Y-axis : iPulSciNum [1])	1 to 65535
	int iPulSciDen[2]	Denominator of pulse scale (X-axis : iPulSciDen [0], Y-axis : iPulSciDen [1])	1 to 65535

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3

void main()
{

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    PMC_PARADATA Data; //Defining structure variable
    PMC_PARADATA *pData = &Data;

    autpmc_GetParaPMAII (PORTNUM, Node01, FPMC_X_AXIS, pData);

    printf("PulseType : %d\n", pData->iPulseType);

    if(pData->bErrorState[0]||pData->bErrorState[1]!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

3.4 autpmc_GetParaHSMAll

This function, `autpmc_GetParaHSMAll`, is for loading all related parameters of home search mode at PMC-2HSP/2HSN.

(1) Syntax

```
struct PMC_PARADATA *autpmc_GetParaHSMAll(
    int PortNum,
    char nNodeId,
    char axis,
    PMC_PARADATA *pData
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- pData
Loads and saves the related parameters' information of home search mode.

Structure name	Variable format	Description	Data value
PMC_PARADATA	int iErrorState	Check error status.	0 : The command is normally executed. 3 : Invalid node ID is entered. 4 : Invalid axis is entered. 5 : Invalid data is entered.
	BOOL bHomMod1[2]	Enable/Disable step 1 of home search mode (X-axis : bHomMod1 [0], Y-axis : bHomMod1 [1])	0 : Disable 1 : Enable
	BOOL bHomMod1Dir[2]	Step 1 search direction of home search mode (X-axis : bHomMod1Dir [0], Y-axis : bHomMod1Dir [1])	0 : + direction 1 : - direction
	BOOL bHomMod2[2]	Enable/Disable step 2 of home search mode (X-axis : bHomMod2 [0], Y-axis : bHomMod2 [1])	0 : Disable 1 : Enable
	BOOL bHomMod2Dir[2]	Step 2 search direction of home search mode (X-axis : bHomMod2Dir [0], Y-axis : bHomMod2Dir [1])	0 : + 1 : -
	BOOL bHomMod3[2]	Enable/Disable step 3 of home search mode	0 : Disable 1 : Enable

Structure name	Variable format	Description	Data value
		(X-axis : bHomMod3 [0], Y-axis : bHomMod3 [1])	
	BOOL bHomMod3Dir[2]	Step 3 search direction of home search mode (X-axis : bHomMod3Dir [0], Y-axis : bHomMod3Dir [1])	0 : + 1 : -
	BOOL bHomMod4[2]	Enable/Disable step 4 of home search mode (X-axis : bHomMod4 [0], Y-axis : bHomMod4 [1])	0 : Disable 1 : Enable
	BOOL bHomMod4Dir[2]	Step 4 search direction of home search mode (X-axis : bHomMod4Dir [0], Y-axis : bHomMod4Dir [1])	0 : + 1 : -
	BOOL bHomEndPosClr[2]	Enable/Disable reset of position counter (X-axis : bHomEndPosClr [0], Y-axis : bHomEndPosClr [1])	0 : Disable 1 : Enable
	BOOL bHomSig0Lev[2]	Logic level low/high of near home signal(STOP 0) (X-axis : bHomSig0Lev [0], Y-axis : bHomSig0Lev [1])	0 : Low 1 : High
	BOOL bHomSig1Lev[2]	Logic level low/high of home signal(STOP1) (X-axis : bHomSig1Lev [0], Y-axis : bHomSig1Lev [1])	0 : Low 1 : High
	BOOL bHomSig2Lev[2]	Logic level low/high of encoder Z-phase signal(STOP2) (X-axis : bHomSig2Lev [0], Y-axis : bHomSig2Lev [1])	0 : Low 1 : High
	int iHomLowSpd[2]	Home search low speed (X-axis : iHomLowSpd [0], Y-axis : iHomLowSpd [1])	1 to 8000
	int iHomHighSpd[2]	Home search high speed (X-axis : iHomHighSpd [0], Y-axis : iHomHighSpd [1])	1 to 8000
	long lHomOffset[2]	High speed offset position of home search step 4 (X-axis : lHomOffset [0], Y-axis : lHomOffset [1])	0~8388607

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);

PMC_PARADATA Data; //Defining structure variable
PMC_PARADATA *pData = &Data;

autpmc_GetParaHSMAll (PORTNUM, Node01, FPMC_X_Y_AXIS, pData);

printf(" X-axis Step 1 Enable : %d\n Y-axis Step 1 Enable : %d\n", pData->bHomMod1[0],
pData->bHomMod1[1]);

if(pData->bErrorState[0]||pData->bErrorState[1]!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.5 autpmc_GetLmtStopMod

This function, `autpmc_GetLmtStopMod`, is for loading the set limit stop mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetLmtStopMod(
int PortNum,
char nNodeId,
char axis,
BOOL *bStopType
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bStopType

Loads `FPMC_INSTANTSTOP(0)` at instant stop setting. Loads `FPMC_SLOWSTOP(1)` at slop stop.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

BOOL StopType=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetLmtStopMod (PORTNUM, Node01, FPMC_X_AXIS, &StopType);  
printf("X-axis StopType : %d\n", StopType);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.6 autpmc_GetLmtActLev

This function, `autpmc_GetLmtActLev`, is for loading the set limit signal logic level at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetLmtActLev(
  int PortNum,
  char nNodeId,
  char axis,
  BOOL *bLevel
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bLevel**
Loads `FPMC_HIGH(1)` when set logic level of limit input signal is high. Loads `FPMC_LOW(0)` when set logic level of limit input signal is low.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  BOOL bLevel=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetLmtActLev (PORTNUM, Node01, FPMC_X_AXIS, &bLevel);  
printf("X-axis bLevel : %d\n", bLevel);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.7 autpmc_GetSCurve

This function, `autpmc_GetSCurve`, is for loading enable/disable setting of S-curve acceleration/deceleration at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetSCurve(
int PortNum,
char nNodeID,
char axis,
BOOL *bEnable
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeID

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bEnable

Loads `FPMC_ENABLE(1)` when S-curve acceleration/deceleration is set enable. Loads `FPMC_DISABLE(0)` when S-curve acceleration/deceleration is set disable.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

BOOL bEnable=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetSCurve (PORTNUM, Node01, FPMC_X_AXIS, &bEnable);  
printf("X-axis bEnable : %d\n", bEnable);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.8 autpmc_GetEndPEnable

This function, `autpmc_GetEndPEnable`, is for loading enable/disable setting of drive end pulse at PMC-2HSP/2HSN .

(1) Syntax

```
int autpmc_GetEndPEnable(
int PortNum,
char nNodeID,
char axis,
BOOL *bEnable
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeID

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bEnable

Loads `FPMC_ENABLE(1)` when drive end pulse is set enable. Loads `FPMC_DISABLE(0)` when drive end pulse is set disable.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

BOOL bEnable=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetEndPEnable (PORTNUM, Node01, FPMC_X_AXIS, &bEnable);  
  
printf("X-axis bEnable : %d\n", bEnable);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.9 autpmc_GetDecValue

This function, `autpmc_GetDecValue`, is for loading setting of trapezoidal acceleration/ deceleration drive at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetDecValue(
  int PortNum,
  char nNodeID,
  char axis,
  BOOL *bEnable
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeID

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bEnable

Loads `FPMC_ACCEL(0)` at acceleration setting. Loads `FPMC_DECEL(1)` at deceleration setting.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  BOOL bDec=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetDecValue (PORTNUM, Node01, FPMC_X_AXIS, &bDec);  
printf("X-axis bDec : %d\n", bDec);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.10 autpmc_GetSofLmtEnable

This function, `autpmc_GetSofLmtEnable`, is for loading enable/disable setting of software limit at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetSofLmtEnable(
  int PortNum,
  char nNodeId,
  char axis,
  BOOL *bEnable
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bEnable

Loads `FPMC_ENABLE(0)` when software limit is set enable. Loads `FPMC_DISABLE(1)` when software limit is set disable.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  BOOL bEnable=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetSofLmtEnable (PORTNUM, Node01, FPMC_X_AXIS, &bEnable);  
printf("X-axis bEnable : %d\n", bEnable);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.11 autpmc_GetPowHomStart

This function, `autpmc_GetPowHomStart`, is for loading enable/disable setting of automatic start of power-on home search at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetPowHomStart(
int PortNum,
char nNodeId,
char axis,
BOOL *bEnable
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bEnable

Loads `FPMC_ENABLE(1)` when automatic start of power-on home search is set enable.
Loads `FPMC_DISABLE(0)` when automatic start of power-on home search is set disable.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

BOOL bEnable=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetPowHomStart (PORTNUM, Node01, FPMC_X_AXIS, &bEnable);  
printf("X-axis bEnable : %d\n", bEnable);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.12 autpmc_GetPowPgmStart

This function, `autpmc_GetPowPgmStart`, is for loading enable/disable setting of automatic start of power-on program at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetPowPgmStart(
  int PortNum,
  char nNodeId,
  char axis,
  BOOL *bEnable
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bEnable**
Loads `FPMC_ENABLE(1)` when automatic start of power-on program is set enable. Loads `FPMC_DISABLE(0)` when automatic start of power-on program is set disable.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  BOOL bEnable=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetPowPgmStart (PORTNUM, Node01, FPMC_X_AXIS, &bEnable);  
printf("X-axis bEnable : %d\n", bEnable);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.13 autpmc_GetInputLev

This function, `autpmc_GetInputLev`, is for loading active level of general input 0, 1 at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetInputLev(
  int PortNum,
  char nNodeId,
  char axis,
  BOOL bInPort,
  BOOL *bActLev
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bInPort**
Enter `FPMC_INPORT0(0)` to select general input 0. Enter `FPMC_INPORT1(1)` to select general input 1.
- **bActLev**
Loads `FPMC_LOW(0)` when set active level is low. Loads `FPMC_HIGH(1)` when set active level is high.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Enters invalid data.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
```

```
int Flag=0;

BOOL bActLev=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_GetInputLev (PORTNUM, Node01, FPMC_X_AXIS, 0, &bActLev);

printf("X-axis bActLev : %d\n", bActLev);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.14 autpmc_GetPulseType

This function, `autpmc_GetPulseType`, is for loading pulse input method(1PULSE/2PULSE) of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetPulseType(
    int PortNum,
    char nNodeID,
    int *iPulseType
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeID**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **iPulseType**
Loads `FPMC_1PULSETYPE(1)` when pulse input method is 1PULSE. Loads `FPMC_2PULSETYPE(2)` when pulse input method is 2PULSE.

(3) Return value

Item	Definition	Return value	Description
Normal	<code>FPMC_OK</code>	0	The command is normally executed.
Input error	<code>FPMC_INVALID_NODE</code>	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    int iPulseType=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_GetPulseType (PORTNUM, Node01, &iPulseType);

    printf("X-axis iPulseType : %d\n", iPulseType);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }
}
```

```
    autpmc_Close(PORTNUM);  
}
```

3.15 autpmc_GetSpdMul

This function, autpmc_GetSpdMul, is for loading speed multiplier of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetSpdMul(
int PortNum,
char nNodeId,
char axis,
int *iSpdMul
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iSpdMul

Loads the set speed multiplier. (1 to 500)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
```

```
{
int Flag=0;
```

```
int iSpdMul=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetSpdMul (PORTNUM, Node01, FPMC_X_AXIS, &iSpdMul);
```

```
printf("X-axis iSpdMul : %d\n", iSpdMul);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.16 autpmc_GetJrkSpd

This function, `autpmc_GetJrkSpd`, is for loading jerk speed of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetJrkSpd(
int PortNum,
char nNodeId,
char axis,
int *iJrkSpd
);
```

(2) Parameter

▪ `nNodeId`

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

▪ `axis`

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ `iJrkSpd`

Loads the set jerk. (1 to 65,535)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
int Flag=0;
```

```
int iJrkSpd=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetJrkSpd (PORTNUM, Node01, FPMC_X_AXIS, &iJrkSpd);
```

```
printf("X-axis iJrkSpd : %d\n", iJrkSpd);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.17 autpmc_GetAccSpdRate

This function, autpmc_GetAccSpdRate, is for loading acceleration rate of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetAccSpdRate(
int PortNum,
char nNodeId,
char axis,
int *iAccSpdRate
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ iAccSpdRate

Loads the set acceleration rate. (1 to 8,000)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
```

```
{
int Flag=0;
```

```
int iAccSpdRate=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetAccSpdRate (PORTNUM, Node01, FPMC_X_AXIS, &iAccSpdRate);
```

```
printf("X-axis iAccSpdRate : %d\n", iAccSpdRate);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.18 autpmc_GetDecSpdRate

This function, autpmc_GetDecSpdRate, is for loading acceleration rate of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetDecSpdRate(
int PortNum,
char nNodeId,
char axis,
int *iDecSpdRate
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iDecSpdRate
Loads the set acceleration rate. (1 to 8,000)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

int iDecSpdRate=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetDecSpdRate (PORTNUM, Node01, FPMC_X_AXIS, &iDecSpdRate);  
printf("X-axis iDecSpdRate : %d\n", iDecSpdRate);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.19 autpmc_GetStrSpd

This function, autpmc_GetStrSpd, is for loading start speed of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetStrSpd(
int PortNum,
char nNodeId,
char axis,
int *iStrSpd
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ iStrSpd

Loads the set start speed. (1 to 8,000)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

int iStrSpd=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetStrSpd (PORTNUM, Node01, FPMC_X_AXIS, &iStrSpd);  
printf("X-axis iStrSpd : %d\n", iStrSpd);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.20 autpmc_GetCurDrvSpd

This function, autpmc_GetDrvSpd, is for loading current drive speed of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetCurDrvSpd(
int PortNum,
char nNodeId,
char axis,
int *iDrvSpd
);
```

(2) Parameter

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ iDrvSpd

Loads the set drive speed. (1 to 8,000)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
int Flag=0;
```

```
int iDrvSpd=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetCurDrvSpd (PORTNUM, Node01, FPMC_X_AXIS, &iDrvSpd);
```

```
printf("X-axis iDrvSpd : %d\n", iDrvSpd);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.21 autpmc_GetDrvSpdPgm

This function, autpmc_GetDrvSpdPgm, is for loading drive speed of PMC-2HSP/2HSN for using at program mode.

(1) Syntax

```
int autpmc_GetDrvSpdPgm(
  int PortNum,
  char nNodeId,
  char axis,
  int nDrvIndex,
  int *iDrvSpd
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nDrvIndex

Enter drive speed index. The variable value is 1 to 4.

- iDrvSpd

Loads the set drive speed. (1 to 8,000)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  int iDrvSpd=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_GetDrvSpdPgm (PORTNUM, Node01, FPMC_X_AXIS, 1, &iDrvSpd);
printf("X-axis iDrvSpd : %d\n", iDrvSpd);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.22 autpmc_GetTimPgm

This function, autpmc_GetTimPgm, is for loading post-timer of PMC-2HSP/2HSN for using at program mode.

(1) Syntax

```
int autpmc_GetTimPgm(
int PortNum,
char nNodeId,
char axis,
int nIndex,
int *iPostTim
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nIndex
Enter post timer index. The valid value is 1 to 3.
- iPostTim
Loads the set post timer. (1 to 8,000)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;
```

```
int iPostTim=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_GetTimPgm (PORTNUM, Node01, FPMC_X_AXIS, 1, &iPostTim);

printf("X-axis iPostTim : %d\n", iPostTim);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.23 autpmc_GetSofLmt

This function, autpmc_GetSofLmt, is for loading software limit of PMC-2HSP/2HSN. (proportion to pulse scale)

(1) Syntax

```
int autpmc_GetSofLmt(
int PortNum,
char nNodeId,
char axis,
int iDirection,
long *ISoftLmt
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iDirection
Enter FPMC_PLUS(0) to set '+' direction limit . Enter FPMC_MINUS(1) to set '-' direction limit.
- ISoftLmt
Loads the set software limit. (-8,388,608 to 8,388,607)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Enters invalid data.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;
```

```
long ISoftLmt=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_GetSofLmt (PORTNUM, Node01, FPMC_X_AXIS, 0, &ISoftLmt);

printf("X-axis ISoftLmt : %ld\n", ISoftLmt);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.24 autpmc_GetEndPWidth

This function, autpmc_GetEndPWidth, is for loading drive end pulse width of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetEndPWidth(
int PortNum,
char nNodeId,
char axis,
int *iEndPWidth
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iEndPWidth
Load the set drive end pulse width. (1 to 65,535)
- Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(3) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
int Flag=0;
```

```
int iEndPWidth=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetEndPWidth (PORTNUM, Node01, FPMC_X_AXIS, &iEndPWidth);
```

```
printf("X-axis iEndPWidth : %d\n", iEndPWidth);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.25 autpmc_GetPulSciNum

This function, autpmc_GetPulSciNum, is for loading numerator of pulse scale of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetPulSciNum(
int PortNum,
char nNodeId,
char axis,
int *iPulSci
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ iPulSci

Loads the set numerator of pulse scale. (1 to 65,535)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
```

```
{
int Flag=0;
```

```
int iPulSci=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetPulScINum (PORTNUM, Node01, FPMC_X_AXIS, &iPulScI);  
printf("X-axis iPulScI : %d\n", iPulScI);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.26 autpmc_GetPulSciDen

This function, autpmc_GetPulSciDen, is for loading denominator of pulse scale of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetPulSciDen(
int PortNum,
char nNodeId,
char axis,
int *iPulSci
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iPulSci

Loads the set denominator of pulse scale. (1 to 65,535)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
```

```
{
int Flag=0;
```

```
int iPulSci=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetPulScDen (PORTNUM, Node01, FPMC_X_AXIS, &iPulScI);  
printf("X-axis iPulScI : %d\n", iPulScI);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.27 autpmc_GetHomMod

This function, autpmc_GetHomMod, is for loading home search mode of PMC-2HSP/2HSN.

(1) Syntax

```
struct HOMMOD *autpmc_GetHomMod(
  int PortNum,
  char nNodeId,
  char axis,
  int nStepNo,
  HOMMOD *pMode
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ nStepNo

Enter step number. The valid value is 1 to 4.

▪ pMode

Loads enable/disable and direction of set home search mode.

Structure name	Variable format	Description	Data value
HOMMODE	BOOL bEnable[2] bEable[0] : X-axis bEable[1] : Y-axis	Enable/Disable home search	FPMC_ENABLE(1)/ FPMC_DISABLE(0)
	BOOL bDirection[2] bDirection [0] : X-axis bDirection [1] : Y-axis	Home search direction	FPMC_PLUS(0)/ FPMC_MINUS(1)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Enters invalid data.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3

void main()
{

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    HOMMOD Mode; //Defining structure variable
    HOMMOD *pMode = &Mode;

    autpmc_GetHomMod (PORTNUM, Node01, FPMC_X_Y_AXIS, 1, pMode);

    printf(" X-axis bEnable : %d\n Y-axis bEnable : %d\n", pMode->bEnable[0], pMode->bEnable[1]);

    if(pMode->bErrorState[0]||pMode->bErrorState[1]!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

3.28 autpmc_GetHomEndPosClr

This function, `autpmc_GetHomEndPosClr`, is for loading enable/disable setting of position counter at the end of home search at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetHomEndPosClr(
    int PortNum,
    char nNodeId,
    char axis,
    BOOL *bClear
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bClear**
Loads `FPMC_ENABLE(1)` when using position counter reset. Loads `FPMC_DISABLE(0)` when not using position counter reset.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    BOOL bClear=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetHomEndPosClr (PORTNUM, Node01, FPMC_X_AXIS, &bClear);  
printf("X-axis bClear : %d\n", bClear);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.29 autpmc_GetHomSigLev

This function, autpmc_GetHomSigLev, is for loading logic level of home signal at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetHomSigLev(
  int PortNum,
  char nNodeId,
  char axis,
  int nHomSigNo,
  BOOL *bLevel
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nHomSigNo
Enter FPMC_HSTOP0(0) to select near home signal, FPMC_HSTOP1(1) to select home signal, or FPMC_HSTOP2(2) to select encoder Z-phase signal.
- bLevel
Loads FPMC_LOW(0) when set logic level of home signal is low. Loads FPMC_HIGH(1) when set logic level of home signal is high.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Enters invalid data.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;
```

```
BOOL bLevel=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_GetHomSigLev (PORTNUM, Node01, FPMC_X_AXIS, 0, &bLevel);

printf("X-axis bLevel : %d\n", bLevel);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.30 autpmc_GetHomSpd

This function, autpmc_GetHomSpd, is for loading home search speed of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetHomSpd(
  int PortNum,
  char nNodeId,
  char axis,
  BOOL bSpd,
  int *iSpd
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bSpd

Enter FPMC_LOW(0) for loading home search low speed. Enter FPMC_HIGH(1) for loading home search high speed.

▪ iSpd

Loads the set home search speed. (1 to 8,000)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  int iSpd=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_GetHomSpd (PORTNUM, Node01, FPMC_X_AXIS, 0, &iSpd);
printf("X-axis Low HomeSpeed : %d\n", iSpd);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.31 autpmc_GetHomOffset

This function, autpmc_GetHomOffset, is for loading high speed offset position of home search step 4 at PMC-2HSP/2HSN. (proportion to pulse scale)

(1) Syntax

```
int autpmc_GetHomOffset(
int PortNum,
char nNodeId,
char axis,
long *IOffset
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- IOffset
Loads the set high speed offset position of home search step 4. (0 to 8,388,607)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

long IOffset=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetHomOffset (PORTNUM, Node01, FPMC_X_AXIS, &IOffset);  
printf("X-axis HomeSearchOffset : %ld\n", IOffset);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.32 autpmc_SetLmtStopMod

This function, autpmc_SetLmtStopMod, is for setting limit stop mode of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetLmtStopMod(
int PortNum,
char nNodeId,
char axis,
BOOL bInstant
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bInstant
Enter FPMC_INSTANT(0) for instant mode. Enter FPMC_SLOW(1) for slow mode.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Enters invalid data.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetLmtStopMod(PORTNUM, Node01, FPMC_X_Y_AXIS, 0);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.33 autpmc_SetLmtActLev

This function, `autpmc_SetLmtActLev`, is for activating limit signal logic level of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetLmtActLev(
int PortNum,
char nNodeId,
char axis,
BOOL bLmtActLev
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bLmtActLev

Enter `FPMC_HIGH(1)` when logic level of limit input signal is high. Enter `FPMC_LOW(0)` when logic level of limit input signal is low.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Enter invalid data.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_SetLmtActLev (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.34 autpmc_SetSCurve

This function, `autpmc_SetSCurve`, is for setting enable/disable S-curve acceleration/deceleration at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetSCurve(
    int PortNum,
    char nNodeID,
    char axis,
    BOOL bEnable
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeID

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bEnable

Enter `FPMC_ENABLE(1)` to use S-curve acceleration/deceleration. Enter `FPMC_DISABLE(0)` not to use S-curve acceleration/deceleration .

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
    int Flag=0;
```

```
    autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_SetSCurve (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.35 autpmc_SetEndPEnable

This function, autpmc_SetEndPEnable, is for setting enable/disable drive end pulse at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetEndPEnable(
  int PortNum,
  char nNodeId,
  char axis,
  BOOL bEnable
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

(3) bEnable

Enter FPMC_ENABLE(1) to use drive end pulse. Enter FPMC_DISABLE(0) not to use drive end pulse.

(4) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(5) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_SetEndPEnable (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.36 autpmc_SetDecValue

This function, autpmc_SetDecValue, is for setting symmetry/asymmetry of trapezoidal acceleration/deceleration drive at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetDecValue(
    int PortNum,
    char nNodeId,
    char axis,
    BOOL bDec
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bDec

Enter FPMC_ACCEL(0) to use acceleration. Enter FPMC_DECEL(1) to use deceleration.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
    int Flag=0;
```

```
    autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
    Flag = autpmc_SetDecValue (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.37 autpmc_SetSofLmtEnable

This function, `autpmc_SetSofLmtEnable`, for setting enable/disable software limit at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetSofLmtEnable(
int PortNum,
char nNodeId,
char axis,
BOOL bEnable
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bEnable

Enter `FPMC_ENABLE(0)` to use software limit. Enter `FPMC_DISABLE(1)` not to use software limit.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_SetSofLmtEnable (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.38 autpmc_SetPowHomStart

This function, `autpmc_SetPowHomStart`, is for setting enable/disable automatic start of power-on home search at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetPowHomStart(
  int PortNum,
  char nNodeID,
  char axis,
  BOOL bEnable
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeID

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bEnable

Enter `FPMC_ENABLE(1)` to use automatic start of power-on home search. Enter `FPMC_DISABLE(0)` not to use automatic start of power-on home search.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
  int Flag=0;
```

```
  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_SetPowHomStart (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.39 autpmc_SetPowPgmStart

This function, `autpmc_SetPowPgmStart`, is for setting enable/disable automatic start of power-on program at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetPowPgmStart(
  int PortNum,
  char nNodeId,
  char axis,
  BOOL bEnable
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bEnable**
Enter `FPMC_ENABLE(1)` to use automatic start of power-on program. Enter `FPMC_DISABLE(0)` not to use automatic start of power-on program.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_SetPowPgmStart (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.40 autpmc_SetInputLev

This function, `autpmc_SetInputLev`, is for setting active level of general input 0, 1 at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetInputLev(
int PortNum,
char nNodeId,
char axis,
BOOL bInPort,
BOOL bActLev
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bInPort

Enter `FPMC_INPORT(0)` to set general input 0. Enter `FPMC_INPORT1(1)` to set general input 1.

▪ bActLev

Enter `FPMC_LOW(0)` to set active level as low. Enter `FPMC_HIGH(1)` to set active level as high.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetInputLev (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 0);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.41 autpmc_SetPulseType

This function, `autpmc_SetPulseType`, is for selecting pulse input method(1PULSE/2PULSE) of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetPulseType(
int PortNum,
char nNodeID,
int iPulseType
);
```

(2) Parameter

- `nNodeID`
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- `iPulseType`
Enter `FPMC_SETPULSE1(1)` at 1PULSE input method. Enter `FPMC_SETPULSE2(2)` at 2PULSE input method.

(3) Return value

Item	Definition	Return value	Description
Normal	<code>FPMC_OK</code>	0	The command is normally executed.
Input error	<code>FPMC_INVALID_NODE</code>	3	Invalid node ID is entered.
	<code>FPMC_INVALID_AXIS</code>	4	Invalid axis is entered.
	<code>FPMC_INVALID_DATA</code>	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetPulseType (PORTNUM, Node01, 1);

if(Flag!=FPMC_OK)
{
printf("error!\n");
return;
}

autpmc_Close(PORTNUM);
}
```

3.42 autpmc_SetSpdMul

This function, autpmc_SetSpdMul, is for setting speed multiplier of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetSpdMul(
int PortNum,
char nNodeId,
char axis,
int iSpdMul
);
```

(2) Parameter

- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iSpdMul
Enter speed multiplier. The valid value is 1 to 500.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetSpdMul(PORTNUM, Node01, FPMC_X_Y_AXIS, 100);

if(Flag!=FPMC_OK)
{
printf("error!\n");
```

```
        return;  
    }  
  
    autpmc_Close(PORTNUM);  
}
```

3.43 autpmc_SetJrkSpd

This function, autpmc_SetJrkSpd, is for setting jerk speed of PMC-2HSP/2HSN.

(1) Syntax

```
autpmc_SetJrkSpd(
  int PortNum,
  char nNodeId,
  char axis,
  int iJrkSpd
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iJrkSpd
Enter jerk speed. The valid value is 1 to 65,535.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  Flag = autpmc_SetJrkSpd (PORTNUM, Node01, FPMC_X_Y_AXIS, 1000);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.44 autpmc_SetAccSpdRate

This function, autpmc_SetAccSpdRate, is for setting acceleration rate of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetAccSpdRate(
int PortNum,
char nNodeId,
char axis,
int iAccSpdRate
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iAccSpdRate
Enter acceleration rate. The valid value is 1 to 8,000.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetAccSpdRate (PORTNUM, Node01, FPMC_X_Y_AXIS, 1000);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.45 autpmc_SetDecSpdRate

This function, autpmc_SetDecSpdRate, is for setting deceleration rate of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetDecSpdRate(
int PortNum,
char nNodeId,
char axis,
int iDecSpdRate
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iDecSpdRate
Enter deceleration rate. The valid value is 1 to 8,000.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetDecSpdRate (PORTNUM, Node01, FPMC_X_Y_AXIS, 1000);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.46 autpmc_SetStrSpd

This function, autpmc_SetStrSpdRate, is for setting start speed of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetStrSpd(
int PortNum,
char nNodeId,
char axis,
int iStrSpd
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iStrSpd
Enter start speed. The valid value is 1 to 8,000.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetStrSpd(PORTNUM, Node01, FPMC_X_Y_AXIS, 1000);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.47 autpmc_SetDrvSpd

This function, autpmc_SetDrvSpd, is for selecting drive speed of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetDrvSpd(
int PortNum,
char nNodeId,
char axis,
int nDrvIndex
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nDrvIndex
Enter drive speed index. The valid value is 1 to 4.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_SetDrvSpd(PORTNUM, Node01, FPMC_X_AXIS, 1); //Select speed 1 to 4
```

```
autpmc_ABSMove(PORTNUM, Node01, FPMC_X_AXIS, 10000);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.48 autpmc_SetDrvSpdPgm

This function, autpmc_SetDrvSpdPgm, is for setting drive speed of PMC-2HSP/2HSN for using program mode.

(1) Syntax

```
int autpmc_SetDrvSpdPgm(
    int PortNum,
    char nNodeId,
    char axis,
    int nDrvIndex,
    int iDrvSpd
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nDrvIndex
Enter drive speed index. The valid value is 1 to 4.
- iDrvSpd
Enter drive speed. The valid value is 1 to 8,000.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetDrvSpdPgm(PORTNUM, Node01, FPMC_X_AXIS, 1, 1000);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.49 autpmc_SetTimPgm

This function, `autpmc_SetTimPgm`, is for setting post-timer of PMC-2HSP/2HSN for using at program mode.

(1) Syntax

```
int autpmc_SetTimPgm(
    int PortNum,
    char nNodeID,
    char axis,
    int nIndex,
    int iPostTim
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeID**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **nIndex**
Select post timer. The valid value is 1 to 3.
- **iPostTim**
Enter post timer. The valid value is 1 to 65,535, and unit is ms.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetTimPgm (PORTNUM, Node01, FPMC_X_Y_AXIS, 1, 1000);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.50 autpmc_SetSofLmt

This function, autpmc_SetSofLmt, is for setting software limit of PMC-2HSP/2HSN.

(proportion to pulse scale)

(1) Syntax

```
int autpmc_SetSofLmt(
    int PortNum,
    char nNodeID,
    char axis,
    int iDirection,
    long lSoftLmt
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iDirection
Select '+' or '-' direction of each axis.
Enter FPMC_SOFLMT_PLUS(0) to set software limit '+' direction of each axis. Enter FPMC_SOFLMT_MINUS(1) to set software limit '-' direction of each axis.
- lSoftLmt
Enter software limit. The valid value is -8,388,608 to 8,388,607.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
```

```
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetSofLmt(PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 8382607);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.51 autpmc_SetEndPWidth

This function, `autpmc_SetEndPWidth`, is for setting drive end pulse width of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetEndPWidth(
int PortNum,
char nNodeId,
char axis,
int iEndPWidth
);
```

(2) Parameter

- `nNodeId`
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- `axis`
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- `iEndPWidth`
Enter the width of drive end pulse. The valid value is 1 to 65,535, and unit is ms.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetEndPWidth (PORTNUM, Node01, FPMC_X_Y_AXIS, 1000);

if(Flag!=FPMC_OK)
{
printf("error!\n");
```

```
        return;  
    }  
  
    autpmc_Close(PORTNUM);  
}
```

3.52 autpmc_SetPulSciNum

This function, autpmc_SetPulSci, is for setting numerator of pulse scale at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetPulSciNum(
int PortNum,
char nNodeId,
char axis,
int iPulSci
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iPulSci
Enter numerator of pulse scale. The valid value is 1 to 65,535.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetPulSciNum (PORTNUM, Node01, FPMC_X_Y_AXIS, 1000);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.53 autpmc_SetPulSciDen

This function, autpmc_SetPulSci, is for setting denominator of pulse scale at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetPulSciDen(
    int PortNum,
    char nNodeId,
    char axis,
    int iPulSci
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iPulSci
Enter denominator of pulse scale. The valid value is 1 to 65,535.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_SetPulSciDen (PORTNUM, Node01, FPMC_X_Y_AXIS, 1000);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.54 autpmc_SetHomMod

This function, autpmc_SetHomMod, is for setting home search mode at PMC-2HSP/2HSN..

(1) Syntax

```
int autpmc_SetHomMod(
int PortNum,
char nNodeId,
char axis,
int nStepNo,
BOOL bEnable,
BOOL bDirection
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter step number. The valid value is 1 to 4.
- bEnable
Enter FPMC_ENABLE(1) to use home search. Enter FPMC_DISABLE(0) not to use home search.
- bDirection
Enter FPMC_PLUS(0) to set '+' search direction during home searching. Enter FPMC_MINUS(1) to set '-' search direction during home searching.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
```

```
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetHomMod(PORTNUM, Node01, FPMC_X_AXIS, 1, 1, 1);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.55 autpmc_HomStop

This function, autpmc_HomStop, is for stopping home search mode at PMC-2HSP/SHSN.

(1) Syntax

```
int autpmc_HomStop(
int PortNum,
char nNodeId,
char axis
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE is returned when ID is out of range. Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

autpmc_HomRun(PORTNUM, Node01, FPMC_X_AXIS); //Run home search mode

Flag = autpmc_HomStop(PORTNUM, Node01, FPMC_X_AXIS); //Stop home search mode

if(Flag!=FPMC_OK)
```

```
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.56 autpmc_Step1Enable

This function, autpmc_Step1Enable, is for setting step 1 using of home search mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Step1Enable(
int PortNum,
char nNodeId,
char axis,
BOOL bEnable
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bEnable
Enter FPMC_ENABLE(1) to use home search. Enter FPMC_DISABLE(0) not to use home search.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_Step1Enable (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.57 autpmc_Step2Enable

This function, `autpmc_Step2Enable`, is for setting step 2 using of home search mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Step2Enable(
int PortNum,
char nNodeId,
char axis,
BOOL bEnable
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bEnable**
Enter `FPMC_ENABLE(1)` to use home search. Enter `FPMC_DISABLE(0)` to use home search.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_Step2Enable (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.58 autpmc_Step3Enable

This function, autpmc_Step3Enable, is for setting step 3 using of home search mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Step3Enable(
int PortNum,
char nNodeId,
char axis,
BOOL bEnable
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bEnable
Enter FPMC_ENABLE(1) to use home search. Enter FPMC_DISABLE(0) not to use home search.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_Step3Enable (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.59 autpmc_Step4Enable

This function, autpmc_Step4Enable, is for setting step 4 using of home search mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Step4Enable(
int PortNum,
char nNodeId,
char axis,
BOOL bEnable
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bEnable
Enter FPMC_ENABLE(1) to use home search. Enter FPMC_DISABLE(0) not to use home search.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_Step4Enable (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.60 autpmc_Step1Direction

This function, `autpmc_Step1Direction`, is for setting search direction of step 1 during home searching at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Step1Direction(
int PortNum,
char nNodeId,
char axis,
BOOL bDirection
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bDirection**
Enter `FPMC_PLUS(0)` to set '+' search direction during home searching. Enter `FPMC_MINUS(1)` to set '-' search direction during home searching.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_Step1Direction (PORTNUM, Node01, FPMC_X_Y_AXIS, 1);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.61 autpmc_Step2Direction

This function, `autpmc_Step2Direction`, is for setting search direction of step2 during home searching at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Step2Direction(
int PortNum,
char nNodeId,
char axis,
BOOL bDirection
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bDirection**
Enter `FPMC_PLUS(0)` to set '+' search direction during home searching. Enter `FPMC_MINUS(1)` to set '-' search direction during home searching.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_Step2Direction (PORTNUM, Node01, FPMC_X_Y_AXIS, 1);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.62 autpmc_Step3Direction

This function, `autpmc_Step3Direction`, is for setting search direction of step 3 during home searching at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Step3Direction(
int PortNum,
char nNodeID,
char axis,
BOOL bDirection
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeID**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bDirection**
Enter `FPMC_PLUS(0)` to set '+' search direction during home searching. Enter `FPMC_MINUS(1)` to set '-' search direction during home searching.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_Step3Direction (PORTNUM, Node01, FPMC_X_Y_AXIS, 1);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.63 autpmc_Step4Direction

This function, `autpmc_Step4Direction`, is for setting search direction of step 4 during home searching at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_Step4Direction(
int PortNum,
char nNodeId,
char axis,
BOOL bDirection
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bDirection**
Enter `FPMC_PLUS(0)` to set '+' search direction during home searching. Enter `FPMC_MINUS(1)` to set '-' search direction during home searching.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_Step4Direction (PORTNUM, Node01, FPMC_X_Y_AXIS, 1);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

3.64 autpmc_SetHomEndPosClr

This function, `autpmc_SetHomEndPosClr`, is for resetting position counter at the end of home search at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetHomEndPosClr(
    int PortNum,
    char nNodeId,
    char axis,
    BOOL bEnable
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **bEnable**
Enter `FPMC_ENABLE(1)` to use position counter reset. Enter `FPMC_DISABLE(0)` not to use position counter reset.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_SetHomEndPosClr (PORTNUM, Node01, FPMC_X_Y_AXIS, 0);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.65 autpmc_SetHomSigLev

This function, autpmc_SetHomSigLev, is for setting logic level of home signal at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetHomSigLev(
int PortNum,
char nNodeId,
char axis,
int nHomSigNo,
BOOL bLevel
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nHomSigNo
Enter FPMC_HSTOP0(0) to select near home signal, FPMC_HSTOP1(1) to select home signal, or FPMC_HSTOP2(2) to select encoder Z-phase signal.
- bLevel
Enter FPMC_LOW(0) to set as low. Enter FPMC_HIGH(1) to set as high.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
```

```
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetHomSigLev (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 0);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.66 autpmc_SetHomSpd

This function, autpmc_SetHomSpd, is for setting home search speed of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetHomSpd(
int PortNum,
char nNodeId,
char axis,
BOOL bSpd,
int iSpd
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bSpd
Enter FPMC_LOW(0) to set home search low speed. Enter FPMC_HIGH(1) to set home search high speed.
- iSpd
Enter home search speed. The valid value is 1 to 8,000.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetHomSpd(PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 1000);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

3.67 autpmc_SetHomOffset

This function, `autpmc_SetHomOffset`, is for setting high speed offset position of home search step 4 at PMC-2HSP/2HSN. (proportion to pulse scale)

(1) Syntax

```
int autpmc_SetHomOffset(
int PortNum,
char nNodeID,
char axis,
long IOffset
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- IOffset
Enters high speed offset position of home search step 4. The valid value is 0 to 8,388,607.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetHomOffset(PORTNUM, Node01, FPMC_X_Y_AXIS, 1000);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```


4 I/O Control

4.1 autpmc_GetParallelIO

This function, autpmc_GetParallelIO, is for loading Parallel I/F connector(CN3) input signal of PMC-2HSP/2HSN

(1) Syntax

```
struct PARALLELSTATE *autpmc_GetParallelIO(
    int PortNum,
    char nNodeID,
    PARALLELSTATE *pState
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- pState
Loads signal of Parallel I/F and saves it current variable.

Structure name	Variable format	Description	Data value
PARALLEL STATE	BOOL HOME;	Start home search	0 : OFF/ 1 : ON
	BOOL STROBE;	Start drive	0 : OFF/ 1 : ON
	BOOL X;	Designate X-axis / jog 2 mode Y+	0 : OFF/ 1 : ON
	BOOL Y;	Designate Y-axis / jog 2 mode Y+	0 : OFF/ 1 : ON
	BOOL MODE0;	Designate step 0/ Run+/ jog 2 mode X+	0 : OFF/ 1 : ON
	BOOL MODE1;	Designate step 1/ Run-/ jog 2 mode X-	0 : OFF/ 1 : ON
	BOOL STEPSL0;	Designate step 2/ Designate drive speed 0	0 : OFF/ 1 : ON
	BOOL STEPSL1;	Designate step 3/ Designate drive speed 1	0 : OFF/ 1 : ON
	BOOL STEPSL2;	Designate step 4/ Designate jog	0 : OFF/ 1 : ON
	BOOL STEPSL3;	Designate step 5/ stop drive	0 : OFF/ 1 : ON
	BOOL STEPSL4;	Designate run mode 0	0 : OFF/ 1 : ON
	BOOL STEPSL5;	Designate run mode 1	0 : OFF/ 1 : ON

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
```

```
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    PARALLELSTATE State; //Defining structure variable
    PARALLELSTATE *pState = &State;

    autpmc_GetParallelIO(PORTNUM, Node01, pState);

    printf("start home search : %d\n", pState->HOME);

    if(pState->bErrorState!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

4.2 autpmc_GetAxisIO

This function, autpmc_GetAxisIO, is for loading I/O connector signal of X-axis(CN4) and Y-axis(CN5) at PMC-2HSP/2HSN.

(1) Syntax

```
struct AXISSTATE *autpmc_GetAxisIO(
    int PortNum,
    char nNodeId,
    char axis,
    AXISSTATE *pState
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- pState

Loads I/O signal of CN4 X-axis or CN5 Y-axis and saves it at current variable.

Structure name	Variable format	Description	Data value
PARALLEL STATE	BOOL bHomSig0[2];	Near home (X-axis : bHomSig0 [0], Y-axis : bHomSig0 [1])	0 : OFF/ 1 : ON
	BOOL bHomSig1[2];	Home (X-axis : bHomSig1 [0], Y-axis : bHomSig1 [1])	0 : OFF/ 1 : ON
	BOOL bHomSig2[2];	Encoder Z-phase (X-axis : bHomSig2 [0], Y-axis : bHomSig2 [1])	0 : OFF/ 1 : ON
	BOOL LmtP[2];	Limit+ (X-axis : LmtP [0], Y-axis : LmtP [1])	0 : OFF/ 1 : ON
	BOOL LmtM[2];	Limit- (X-axis : LmtM [0], Y-axis : LmtM [1])	0 : OFF/ 1 : ON
	BOOL EMG[2];	EMG (X-axis : EMG [0], Y-axis : EMG [1])	0 : OFF/ 1 : ON
	BOOL bInput0Lev[2];	general input0 (X-axis : bInput0Lev [0], Y-axis : bInput0Lev [1])	0 : OFF/ 1 : ON
	BOOL bInput1Lev[2];	general input1 (X-axis : bInput1Lev [0], Y-axis : bInput1Lev [1])	0 : OFF/ 1 : ON

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    AXISSTATE State;          //Defining structure variable
    AXISSTATE *pState = &State;

    autpmc_GetAxisIO (PORTNUM, Node01, FPMC_X_AXIS, pState);

    printf(" X-axis near home : %d\n Y-axis near home : %d\n", pState->bHomSig0[0], pState->bHomSig0[1]);

    if(pState->bErrorState[0]||pState->bErrorState[1]!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

4.3 autpmc_SetUserOut

This function, `autpmc_SetUserOut`, is for turning ON/OFF X-axis general output 0/1 pin of CN4 connector or Y-axis general output 0/1 pin of CN5 connector at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_SetUserOut(
    int PortNum,
    char nNodeId,
    char axis,
    BOOL bPort,
    BOOL bOn
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ bPort

Enter `FPMC_OUTPORT0(0)` to set general output 0 pin, or `FPMC_OUTPORT1(1)` for general output 1 pin.

▪ bOn

Enter `FPMC_ON(1)` to turn ON corresponding general output port pin. Enter `FPMC_OFF(0)` to turn OFF corresponding general output port pin.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_SetUserOut(PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 0);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

4.4 autpmc_GetCurPos

This function, `autpmc_GetCurPos`, is for loading current coordinate of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetCurPos(
int PortNum,
char nNodeId,
char axis,
long *ICurPos
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **ICurPos**
Loads current coordinate. (-8,388,608 to 8,388,607)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
nNodeId#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

long ICurPos=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_GetCurPos (PORTNUM, Node01, FPMC_X_AXIS, &ICurPos);
```

```
printf("current position : %ld\n", lCurPos);

if(flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

4.5 autpmc_GetCurPgmNo

This function, `autpmc_GetCurPgmNo`, is for loading currently running program step of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_GetCurPgmNo(
    int PortNum,
    char nNodeId,
    char axis,
    int *iCurPgmNo
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeId**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **iCurPgmNo**
Loads currently running program step. (0 to 199)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    int iCurPgmNo=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_GetCurPgmNo (PORTNUM, Node01, FPMC_X_AXIS, &iCurPgmNo);  
printf("Running Program Step : %d\n", iCurPgmNo);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

4.6 autpmc_GetErrorSt

This function, autpmc_GetErrorSt, is for loading error status of PMC-2HSP/2HSN.

(1) Syntax

```
struct PMC_ERRORSTATE *autpmc_GetErrorSt(
    int PortNum,
    char nNodeId,
    char axis,
    PMC_ERRORSTATE *pError
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- pError
Load current error status.

Structure name	Variable format	Description	Data value
PMC_ERRORSTATE	int iErrorState	Check error status.	FPMC_OK(0) : The command is normally executed. FPMC_INVALID_NODE(3) : Invalid node ID is entered. FPMC_INVALID_AXIS(4) : Invalid axis is entered. FPMC_INVALID_DATA(5) : Invalid data is entered.
	BOOL bSofLmtErrP[2] 1. bSofLmtErrP[0] -> X-axis 2. bSofLmtErrP[1] -> Y-axis	Software limit + error	FPMC_ON(1)/ FPMC_OFF(0)
	BOOL bSofLmtErrM[2] 1. bSofLmtErrM[0] -> X-axis 2. bSofLmtErrM[1] -> Y-axis	Software limit - error	FPMC_ON(1)/ FPMC_OFF(0)
	BOOL bHardLmtErrP[2] 1. bHardLmtErrP[0] -> X-axis 2. bHardLmtErrP[1] -> Y-axis	Hardware limit + error	FPMC_ON(1)/ FPMC_OFF(0)
	BOOL bHardLmtErrM[2] 1. bHardLmtErrM[0] -> X-axis 2. bHardLmtErrM[1] -> Y-axis	Hardware limit - error	FPMC_ON(1)/ FPMC_OFF(0)
	BOOL bEmgErr[2] 1. bEmgErr[0] -> X-axis 2. bEmgErr[1] -> Y-axis	Emergency stop error	FPMC_ON(1)/ FPMC_OFF(0)
	BOOL bPgmErr[2]	Program	FPMC_ON(1)/

Structure name	Variable format	Description	Data value
	1. bPgmErr[0] -> X-axis 2. bPgmErr[1] -> Y-axis	mode error	FPMC_OFF(0)
	BOOL bHomErr[2] 1. bHomErr[0] -> X-axis 2. bHomErr[1] -> Y-axis	Home search mode error	FPMC_ON(1)/ FPMC_OFF(0)
	BOOL bInxErr[2] 1. bInxErr[0] -> X-axis 2. bInxErr[1] -> Y-axis	Index error	FPMC_ON(1)/ FPMC_OFF(0)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    PMC_ERRORSTATE Error; //Defining structure variable
    PMC_ERRORSTATE *pError = &Error;

    autpmc_GetErrorSt (PORTNUM, Node01, FPMC_X_Y_AXIS, pError);

    printf(" X-axis software limit + error : %d\n Y-axis software limit + error : %d\n", pError->bSofLmtErrP[0], pError->bSofLmtErrP[1]);

    if(pError->bErrorState[0]||pError->bErrorState[1]!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

4.7 autpmc_IsRun

This function, autpmc_IsRun, is for loading current running status of PMC-2HSP/2HSN.

(1) Syntax

```
struct PMC_RUNSTATE *autpmc_IsRun(
    int PortNum,
    char nNodeId,
    char axis,
    PMC_RUNSTATE *pRun
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- pRun
Loads current running status.

Structure name	Variable format	Description	Data value
PMC_RUNSTATE	int iErrorState	Check error status.	0 : The command is normally executed. 3 : Invalid node ID is entered. 4 : Invalid axis is entered. 5 : Invalid data is entered.
	BOOL bHomIsRun[2] 1. bHomIsRun[0] ->X-axis 2. bHomIsRun[1] ->Y-axis	Run X-axis home search mode	1 : ON 0 : OFF
	BOOL bJogIsRun[2] 1. bJogIsRun[0] ->X-axis 2. bJogIsRun[1] ->Y-axis	Run X-axis jog mode	1 : ON 0 : OFF
	BOOL bPgmlsRun[2] 1. bPgmlsRun[0] ->X-axis 2. bPgmlsRun[1] ->Y-axis	Run X-axis program mode	1 : ON 0 : OFF

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    PMC_RUNSTATE Run; //Defining structure variable
    PMC_RUNSTATE *pRun = &Run;

    autpmc_IsRun (PORTNUM, Node01, FPMC_X_Y_AXIS, pRun);

    printf(" running X-axis home search mode : %d\n",
pRun->bHomIsRun[0], pRun->bHomIsRun[1]);

    if(pRun->bErrorState[0]||pRun->bErrorState[1]!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

4.8 autpmc_GetModName

This function, autpmc_GetModName, is for loading the model of PMC-2HSP/2HSN.

(1) Syntax

```
struct PMC_SOFTWARE_VERSION *autpmc_GetModName(
    int PortNum,
    char nNodeID,
    PMC_SOFTWARE_VERSION *pVersion
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- pVersion
Loads the model.

Structure name	Variable format	Description	Data value
PMC_SOFTWARE_VERSION	int iErrorState	Check error status.	0 : The command is normally executed. 3 : Invalid node ID is entered. 4 : Invalid axis is entered. 5 : Invalid data is entered.
	char cModName[12];	Loads the model.	PMC-2HSP-USB PMC-2HSP-485 PMC-2HSN-USB PMC-2HSN-485

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    PMC_SOFTWARE_VERSION Version; //Defining structure variable
    PMC_SOFTWARE_VERSION *pVersion = &Version;

    autpmc_GetModName (PORTNUM, Node01, pVersion);
```

```
printf("Model Name: %s\n", pVersion->cModName);

if(pVersion->bErrorState!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

4.9 autpmc_GetSofVer

This function, autpmc_GetSofVer, is for loading firmware version of PMC-2HSP/2HSN.

(1) Syntax

```
struct PMC_SOFTWARE_VERSION *autpmc_GetSofVer(
    int PortNum,
    char nNodeID,
    PMC_SOFTWARE_VERSION *pVersion
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- pVersion
Loads current firmware version. Version format is 4 digits for year, 2 digits for month, 2 digits for day.
E.g.) 20091009 2009. Oct. 09th version

Structure name	Variable format	Description	Data value
PMC_PARADATA	int iErrorState	Check error status.	FPMC_OK(0) : The command is normally executed. FPMC_INVALID_NODE(3) : Invalid node ID is entered. FPMC_INVALID_AXIS(4) : Invalid axis is entered. FPMC_INVALID_DATA(5) : Invalid data is entered.
	char cSofVer[8];	Firmware version	yyyymmdd

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    PMC_SOFTWARE_VERSION Version; //Defining structure variable
    PMC_SOFTWARE_VERSION *pVersion = &Version;
```

```
autpmc_GetSofVer (PORTNUM, Node01, pVersion);  
printf("Software Version: %s\n", pVersion->cSofVer);  
if(pVersion->bErrorState!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

5 Movement

5.1 autpmc_HomRun

This function, autpmc_HomRun, is for running home search mode at PMC-2HSP/SHSN.

(1) Syntax

```
int autpmc_HomRun(
  int PortNum,
  char nNodeId,
  char axis
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_HomRun(PORTNUM, Node01, FPMC_X_Y_AXIS);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

5.2 autpmc_ABSMove

This function, autpmc_ABSMove, is for moving to absolute position by a specified distance from home at PMC-2HSP/2HSN. (proportion to pulse scale)

(1) Syntax

```
int autpmc_ABSMove(
int PortNum,
char nNodeId,
char axis,
long IPos
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- IPos

Enter moving position as absolute value. The available range is -8,388,608 to 8,388,607.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
autpmc_SetDrvSpd(PORTNUM, Node01, FPMC_X_AXIS, 1); //Select speed 1 to 4
```

```
Flag = autpmc_ABSMove(PORTNUM, Node01, FPMC_X_AXIS, 10000);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

5.3 autpmc_INCMove

This function, autpmc_INCMove, is for moving to relative position by a specified distance from current position at PMC-2HSP/2HSN. (proportion to pulse scale)

(1) Syntax

```
int autpmc_INCMove(
int PortNum,
char nNodeId,
char axis,
long IPos
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ IPos

Enter moving position as relative value. The available range is -8,388,608 to 8,388,607.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
autpmc_SetDrvSpd(PORTNUM, Node01, FPMC_X_AXIS, 1); //Select speed 1 to 4
```

```
Flag = autpmc_INCMove(PORTNUM, Node01, FPMC_X_AXIS, 1000);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

5.4 autpmc_ContMove

This function, autpmc_ContMove, is for outputting drive pulse continuously until stop signal input by broadcast at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_ContMove(
  int PortNum,
  char nNodeId,
  char axis,
  BOOL bDirection
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE is returned when ID is out of the range . Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- bDirection

Enter FPMC_PLUS(1) to move '+'. Enter FPMC_MINUS(0) to move '-'.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
  int Flag=0;
```

```
  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
  autpmc_SetDrvSpd(PORTNUM, Node01, FPMC_X_Y_AXIS, 1); //Select speed 1 to 4
```

```
Flag = autpmc_ContMove(PORTNUM, Broadcast, FPMC_X_Y_AXIS, 0);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

5.5 autpmc_LIDMove

This function, autpmc_LIDMove, is for running 2 axes linear interpolation from current coordinate to end coordinate at PMC-2HSP .

(1) Syntax

```
PMC_FUNC autpmc_LIDMove(
  int PortNum,
  BYTE nNodeID,
  BOOL bFLS,
  long IXEndPos,
  long IYEndPos
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- bFLS
Enter FPMC_ON(1) to use constant linear velocity. Enter FPMC_OFF(0) not to use constant linear velocity.
- IXEndPos
Enter X-axis end coordinate. The available range is -8,388,608 to 8,388,607.
- IYEndPos
Enter Y-axis end coordinate. The available range is -8,388,608 to 8,388,607.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  autpmc_SetDrvSpd(PORTNUM, Node01, FPMC_X_Y_AXIS, 1); //Select speed 1 to 4

  Flag = autpmc_LIDMove(PORTNUM, Node01, 0, 1000, 1000);

  if(Flag!=FPMC_OK)
  {
```

```
        printf("error!\n");  
        return;  
    }  
  
    autpmc_Close(PORTNUM);  
}
```

5.6 autpmc_CIDMove

This function, autpmc_CIDMove, is for running circle interpolation drive to clockwise(CW) direction at PMC-2HSP.

(1) Syntax

```
PMC_FUNC autpmc_CIDMove(
    int PortNum,
    BYTE nNodeID,
    BOOL bFLS,
    long IRadius,
    long IMDP
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- bFLS
Enter FPMC_ON(1) to use constant linear velocity. Enter FPMC_OFF(0) not to use constant linear velocity.
- IRadius
Enter radius. The available range is 0 to 8,388,607.
- IMDP
Enter manual deceleration point. The available range is 0 to 268,435,455.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;
    long ManualDecelPoint; //ManualDecelPoint
    int Range; // Speed Multiplier
    long Acceleration; // Acceleration rate
    long Deceleration; // Deceleration rate
    long StVelocity; // Start speed
    long DrVelocity; //Drive speed
    long CtXaxis; //X axis Center position
    long CtYaxis; //Y axis Center position
    long EndXaxis; //X axis End position
```

```
long EndYaxis; //Y axis End position
BOOL CW=1; //Direction
BOOL bDecValue; //Fixed Line Speed;

Range = 10;
Acceleration = 400;
Deceleration = 400;
StVelocity = 50;
DrVelocity = 10;
CtXaxis = 1000;
CtYaxis = 1000;
EndXaxis = 1000;
EndYaxis = 1000;
bDecValue = 1; //Enable;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

ManualDecelPoint = CalculateManualDecelPoint(Range, Acceleration, Deceleration,
StVelocity, DrVelocity, CtXaxis, CtYaxis, EndXaxis, EndYaxis, CW, bDecValue); //Calculate
manual deceleration point

printf("Manual deceleration point : %ld\n", ManualDecelPoint);

Flag = autpmc_CIDMove(PORTNUM, Node01, 0, 10000, ManualDecelPoint);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

5.7 autpmc_FIDMove

This function, autpmc_FIDMove, is for running circular interpolation drive to clockwise(CW) direction at PMC-2HSP.

(1) Syntax

```
PMC_FUNC autpmc_FIDMove(
  int PortNum,
  BYTE nNodeID,
  BOOL bFLS,
  long IXCenPos,
  long IYCenPos,
  long IXEndPos,
  long IYEndPos,
  long IMDP
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- bFLS
Enter FPMC_ON(1) to use constant linear velocity. Enter FPMC_OFF(0) not to use constant linear velocity.
- IXCenPos
Enter X-axis center coordinate. The available range is -8,388,608 to 8,388,607.
- IYCenPos
Enter Y-axis center coordinate. The available range is -8,388,608 to 8,388,607.
- IXEndPos
Enter X-axis end coordinate. The available range is -8,388,608 to 8,388,607.
- IYEndPos
Enter Y-axis end coordinate. The available range is -8,388,608 to 8,388,607.
- IMDP
Enter manual deceleration point. The available range is 0 to 268,435,455.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3
```

```
void main()
{
    int Flag=0;
    long ManualDecelPoint; //ManualDecelPoint
    int Range; // Speed Multiplier
    long Acceleration; // Acceleration rate
    long Deceleration; // Deceleration rate
    long StVelocity; // Start speed
    long DrVelocity; //Drive speed
    long CtXaxis; //X axis Center position
    long CtYaxis; //Y axis Center position
    long EndXaxis; //X axis End position
    long EndYaxis; //Y axis End position
    BOOL CW=1; //Direction
    BOOL bDecValue; //Fiexd Line Speed;

    Range = 10;
    Acceleration = 400;
    Deceleration = 400;
    StVelocity = 50;
    DrVelocity = 10;
    CtXaxis = 1000;
    CtYaxis = 1000;
    EndXaxis = 1000;
    EndYaxis = 1000;
    bDecValue = 1; //Enable;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    ManualDecelPoint = CalculateManualDecelPoint(Range, Acceleration, Deceleration,
    StVelocity, DrVelocity, CtXaxis, CtYaxis, EndXaxis, EndYaxis, CW, bDecValue); //Calculate
    manual deceleration point

    printf("manual deceleration point : %ld\n", ManualDecelPoint);

    Flag = autpmc_FIDMove(PORTNUM, Node01, CW, CtXaxis, CtYaxis, EndXaxis, EndYaxis,
    ManualDecelPoint);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

5.8 autpmc_RIDMove

This function, autpmc_RIDMove, is for running circular interpolation drive to counter clockwise(CCW) direction at PMC-2HSP.

(1) Syntax

```
PMC_FUNC autpmc_RIDMove(
  int PortNum,
  BYTE nNodeID,
  BOOL bFLS,
  long IXCenPos,
  long IYCenPos,
  long IXEndPos,
  long IYEndPos,
  long IMDP
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- bFLS
Enter FPMC_ON(1) to use constant linear velocity. Enter FPMC_OFF(0) not to use constant linear velocity.
- IXCenPos
Enter X-axis center coordinate. The available range is -8,388,608 to 8,388,607.
- IYCenPos
Enter Y-axis center coordinate. The available range is -8,388,608 to 8,388,607.
- IXEndPos
Enter X-axis end coordinate. The available range is -8,388,608 to 8,388,607.
- IYEndPos
Enter Y-axis end coordinate. The available range is -8,388,608 to 8,388,607.
- IMDP
Enter manual deceleration point. The available range is 0 to 268,435,455.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3
```

```
void main()
{
    int Flag=0;
    long ManualDecelPoint; //ManualDecelPoint
    int Range; // Speed Multiplier
    long Acceleration; // Acceleration rate
    long Deceleration; // Deceleration rate
    long StVelocity; // Start speed
    long DrVelocity; //Drive speed
    long CtXaxis; //X axis Center position
    long CtYaxis; //Y axis Center position
    long EndXaxis; //X axis End position
    long EndYaxis; //Y axis End position
    BOOL CCW = 0; //Direction
    BOOL bDecValue; //Fiexd Line Speed;

    Range = 10;
    Acceleration = 1000;
    Deceleration = 1000;
    StVelocity = 500;
    DrVelocity = 1000;
    CtXaxis = 1000;
    CtYaxis = 1000;
    EndXaxis = 3000;
    EndYaxis = 3000;
    bDecValue = 1; //Enable;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    ManualDecelPoint = CalculateManualDecelPoint(Range, Acceleration, Deceleration,
    StVelocity, DrVelocity, CtXaxis, CtYaxis, EndXaxis, EndYaxis, CCW, bDecValue); //Calculate
    manual deceleration point

    printf("manual deceleration point : %ld\n", ManualDecelPoint);

    Flag = autpmc_RIDMove(PORTNUM, Node01, bDecValue, CtXaxis, CtYaxis, EndXaxis,
    EndYaxis, ManualDecelPoint);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6 Program Control

6.1 autpmc_PgmRun

This function, autpmc_PgmRun, is for running program mode by broadcast at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmRun(
  int PortNum,
  char nNodeId,
  char axis,
  int iStepNo
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE is returned when ID is out of the range. Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

▪ iStepNo

Enter program start address. The available range is 0 to 199.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
autpmc_PgmABS (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 10000, 1, 0, 0, 0); //Drive  
program absolute position
```

```
Flag = autpmc_PgmRun(PORTNUM, Broadcast, FPMC_X_Y_AXIS, 0); //Run program  
mode (broadcast)
```

```
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}
```

```
autpmc_Close(PORTNUM);  
}
```

6.2 autpmc_PgmStepRun

This function, autpmc_PgmStepRun, is for running one step at program mode of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmStepRun(
  int PortNum,
  char nNodeId,
  char axis,
  int iStepNo
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE is returned when ID is out of the range. Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- iStepNo

Enter program address to run one step. The available range is 0 to 199.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"
```

```
#define PORTNUM 3
```

```
void main()
{
  int Flag=0;
```

```
  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
    autpmc_PgmABS (PORTNUM, Node01, FPMC_X_AXIS, 0, 10000, 1, 0, 0, 0); //Drive
program absolute position

    autpmc_PgmINC (PORTNUM, Node01, FPMC_X_AXIS, 1, 1000, 1, 0, 0, 0); //Drive
program relative position

    Flag = autpmc_PgmStepRun(PORTNUM, Node01, FPMC_X_AXIS, 0); // Run one step
from start address

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6.3 autpmc_PgmPause

This function, autpmc_PgmPause, is for pausing program mode by broadcast at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmPause(
  int PortNum,
  char nNodeId,
  char axis
);
```

(2) Parameter

▪ PortNum

Enter serial port to execute the command.

▪ nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE is returned when ID is out of the range. Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.

▪ axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  autpmc_PgmABS (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 10000, 1, 0, 0, 0); //Drive
  program absolute position

  autpmc_PgmRun(PORTNUM, Node01, FPMC_X_Y_AXIS, 0); //Run program mode
```

```
Flag = autpmc_PgmPause(PORTNUM, Node01, FPMC_X_Y_AXIS); //Pause program
mode

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

6.4 autpmc_PgmReRun

This function, `autpmc_PgmReRun`, is for rerunning program mode from the paused step by broadcast at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmReRun(
  int PortNum,
  char nNodeId,
  char axis
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE` is returned when ID is out of the range. Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.

- axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  autpmc_PgmABS (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 10000, 1, 0, 0, 0); //Drive
  program absolute position
```

```
    autpmc_PgmINC (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 5000, 1, 0, 0, 0); //Drive
program relative position

    autpmc_PgmRun(PORTNUM, Node01, FPMC_X_Y_AXIS, 0); //Run program mode

    autpmc_PgmPause(PORTNUM, Node01, FPMC_X_Y_AXIS); //Pause program mode

    Flag = autpmc_PgmReRun (PORTNUM, Node01, FPMC_X_Y_AXIS); //Rerun program

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6.5 autpmc_PgmStop

This function, `autpmc_PgmStop`, is for forcibly stopping program mode by broadcast function at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmStop(
    int PortNum,
    char nNodeId,
    char axis
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE` is returned when ID is out of the range. Enter broadcast (0x80) and data transfers to every connected PMC-2HSP/2HSN and PC by broadcast function.

- axis

Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    autpmc_PgmABS (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 10000, 1, 0, 0, 0); //Drive
    program absolute position

    autpmc_PgmRun(PORTNUM, Node01, FPMC_X_Y_AXIS, 0); //Run program mode
```

```
Flag = autpmc_PgmStop (PORTNUM, Node01, FPMC_X_Y_AXIS); //Stop program

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

6.6 autpmc_DelPgmData

This function, autpmc_DelPgmData, is for deleting the set step data of program mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_DelPgmData(
  int PortNum,
  char nNodeID,
  char axis,
  int nStepNo
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  Flag = autpmc_DelPgmData (PORTNUM,Node01, FPMC_X_Y_AXIS, 0)
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

6.7 autpmc_DelPgmDataAll

This function, autpmc_DelPgmDataAll, is for deleting all steps data of program mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_DelPgmDataAll(
  int PortNum,
  char nNodeId,
  char axis
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  Flag = autpmc_DelPgmDataAll (PORTNUM, Node01, FPMC_X_Y_AXIS);

  if(Flag!=FPMC_OK)
  {
```

```
        printf("error!\n");  
        return;  
    }  
  
    autpmc_Close(PORTNUM);  
}
```

6.8 autpmc_PgmABS

This function, autpmc_PgmABS, is for moving to absolute position by a specified distance from home in program mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmABS(
  int PortNum,
  char nNodeID,
  char axis,
  int nStepNo,
  long IPos,
  int nSpeed,
  int nTimer,
  BOOL bEndP,
  BOOL bBoth
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeID**
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **nStepNo**
Enter program step number. The available range is 0 to 199.
- **IPos**
Absolute position coordinate (-8,388,608 to 8,388,607)
- **nSpeed**
Speed index (1 to 4)
- **nTimer**
Post-timer index (1 to 3)
- **bEndP**
Drive end pulse (0: Disable, 1: Enable)
- **bBoth**
Drive X, Y-axis simultaneously(0: Disable, 1: Enable)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_PgmABS (PORTNUM, Node01, FPMC_X_AXIS, 0, 10000, 1, 0, 0, 0);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6.9 autpmc_PgmINC

This function, autpmc_PgmINC, is for moving to relative position by a specified distance from current position in program mode of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmINC(
  int PortNum,
  char nNodeID,
  char axis,
  int nStepNo,
  long IPos,
  int nSpeed,
  int nTimer,
  BOOL bEndP,
  BOOL bBoth
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.
- IPos
Absolute position coordinate(-8,388,608 to 8,388,607)
- nSpeed
Speed index(1 to 4)
- nTimer
Post-timer index(1 to 3)
- bEndP
Drive end pulse(0: Disable, 1: Enable)
- bBoth
Drive X, Y-axis simultaneously (0: Disable, 1: Enable)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_PgmINC (PORTNUM, Node01, FPMC_X_AXIS, 0, 10000, 1, 0, 0, 0);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6.10 autpmc_PgmHOM

This function, autpmc_PgmHOM, is for running home search according to the set order of home search mode in program mode of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmHOM(
  int PortNum,
  char nNodeID,
  char axis,
  int nStepNo,
  BOOL bEndP,
  BOOL bBoth
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.
- bEndP
Drive end pulse (0: Disable, 1: Enable)
- bBoth
Drive X, Y-axis simultaneously (0: Disable, 1: Enable)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
```

```
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  Flag = autpmc_PgmHOM (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 1, 1);

  if(Flag!=FPMC_OK)
  {
    printf("error!\n");
    return;
  }

  autpmc_Close(PORTNUM);
}
```

6.11 autpmc_PgmLID

This function, autpmc_PgmLID, is for running 2 axes linear interpolation from current coordinate to end coordinate in program mode at PMC-2HSP.

(1) Syntax

```
int autpmc_PgmLID(
  int PortNum,
  char nNodeID,
  int nStepNo,
  long IXEndPos,
  long IYEndPos,
  BOOL bFLS,
  int nSpeed,
  int nTimer,
  BOOL bEndP
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- nStepNo
Enter program step number. The available range is 0 to 199. 2 steps are assigned.
- IXEndPos
X-axis end coordinate(-8,388,608 to 8,388,607)
- IYEndPos
Y-axis end coordinate(-8,388,608 to 8,388,607)
- bFLS
Constant linear velocity (0: Disable, 1: Enable)
- nSpeed
Speed index(1 to 4)
- nTimer
Post-timer index(1 to 3)
- bEndP
Drive end pulse (0: Disable, 1: Enable)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3
```

```
void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_PgmLID (PORTNUM, Node01, 0, 1000, 1000, 0, 1, 0, 0);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6.12 autpmc_PgmCID

This function, autpmc_PgmCID, is for running circle interpolation drive to clockwise (CW) direction of X, Y-axis in program mode at PMC-2HSP.

(1) Syntax

```
int autpmc_PgmCID(
  int PortNum,
  char nNodeID,
  int nStepNo,
  long IRadius,
  BOOL bFLS,
  int nSpeed,
  int nTimer,
  BOOL bEndP
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- nStepNo
Enter program step number. The available range is 0 to 199. 2 steps are assigned.
- IRadius
Radius coordinate 0 to 8,388,607
- bFLS
Constant linear velocity (0: Disable, 1: Enable)
- nSpeed
Speed index (1 to 4)
- nTimer
Post-timer index (1 to 3)
- bEndP
Drive end pulse (0: Disable, 1: Enable)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
```

```
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_PgmCID (PORTNUM, Node01, 0, 10000, 1, 1, 1, 1);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

6.13 autpmc_PgmFID

This function, autpmc_PgmFID, is for running circular interpolation drive to X, Y-axis clockwise (CW) direction in program mode at PMC-2HSP.

(1) Syntax

```
int autpmc_PgmFID(
  int PortNum,
  char nNodeID,
  int nStepNo,
  long XCenPos,
  long XEndPos,
  long YCenPos,
  long YEndPos,
  BOOL bFLS,
  int nSpeed,
  int nTimer,
  BOOL bEndP
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- nStepNo
Enter program step number. The available range is 0 to 199. 2 steps are assigned.
- XCenPos
X-axis center coordinate -8,388,608 to 8,388,607
- XEndPos
X-axis end coordinate -8,388,608 to 8,388,607
- YCenPos
Y-axis center coordinate -8,388,608 to 8,388,607
- YEndPos
Y-axis end coordinate -8,388,608 to 8,388,607
- bFLS
Constant linear velocity (0: Disable, 1: Enable)
- nSpeed
Speed index (1 to 4)
- nTimer
Post-timer index (1 to 3)
- bEndP
Driver end pulse (0: Disable, 1: Enable)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_PgmFID (PORTNUM, Node01, 0, 1000, 1000, 1000, 1000, 0, 1, 0, 0);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6.14 autpmc_PgmRID

This function, `autpmc_PgmRID`, is for running circular interpolation drive to X, Y-axis counter clockwise (CCW) direction in program mode at PMC-2HSP.

(1) Syntax

```
int autpmc_PgmRID(
  int PortNum,
  char nNodeID,
  int nStepNo,
  long XCenPos,
  long XEndPos,
  long YCenPos,
  long YEndPos,
  BOOL bFLS,
  int nSpeed,
  int nTimer,
  BOOL bEndP
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeID**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **nStepNo**
Enter program step number. The available range is 0 to 199. 2 steps are assigned.
- **XCenPos**
X-axis center coordinate -8,388,608 to 8,388,607
- **XEndPos**
X-axis end coordinate -8,388,608 to 8,388,607
- **YCenPos**
Y-axis center coordinate -8,388,608 to 8,388,607
- **YEndPos**
Y-axis end coordinate -8,388,608 to 8,388,607
- **bFLS**
Constant linear velocity (0: Disable, 1: Enable)
- **nSpeed**
Speed index (1 to 4)
- **nTimer**
Post-timer index (1 to 3)
- **bEndP**
Driver end pulse (0: Disable, 1: Enable)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_PgmRID (PORTNUM, Node01, 0, 1000, 1000, 1000, 1000, 0, 1, 0, 0);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6.15 autpmc_PgmICJ

This function, autpmc_PgmICJ, is for jumping to set step when the selected input port in program mode is active status at PMC-2HSP/2HSN. This function is for running the next step when input port is deactive status.

(1) Syntax

```
int autpmc_PgmICJ(
  int PortNum,
  char nNodeID,
  char axis,
  int nStepNo,
  int nJumpStep,
  int nInputPtNo
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.
- nJumpStep
Step number to jump (0 to 199)
- nInputPtNo
Input port number(0 to 14)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3
```

```
void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_PgmICJ (PORTNUM, Node01, FPMC_X_AXIS, 0, 10, 0);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6.16 autpmc_PgmIRD

This function, `autpmc_PgmIRD`, is for moving next step when the selected input port in program mode is active status at PMC-2HSP/2HSN. This function is for waiting current step until active status of input.

(1) Syntax

```
int autpmc_PgmIRD(
  int PortNum,
  char nNodeID,
  char axis,
  int nStepNo,
  int nInputPtNo
);
```

(2) Parameter

- **PortNum**
Enter serial port to execute the command.
- **nNodeID**
Select the node ID. The range of node ID is 1 to 16. `FPMC_INVALID_NODE(3)` is returned when the node ID is out of the range.
- **axis**
Select the control axis (X-axis, Y-axis). `FPMC_INVALID_AXIS(4)` is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- **nStepNo**
Enter program step number. The available range is 0 to 199.
- **nInputPtNo**
input port number(0 to 14)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;
```

```
autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_PgmIRD (PORTNUM, Node01, FPMC_X_AXIS, 0, 10);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

6.17 autpmc_PgmOPC

This function, autpmc_PgmOPC, is for turning ON/OFF the selected output port in program mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmOPC(
  int PortNum,
  char nNodeID,
  char axis,
  int nStepNo,
  int nOutPtNo,
  BOOL bON
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.
- nOutPtNo
Output port number(0 to 3)
- bON
OFF(0) to ON(1)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
```

```
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  Flag = autpmc_PgmOPC (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 3, 1);

  if(Flag!=FPMC_OK)
  {
    printf("error!\n");
    return;
  }

  autpmc_Close(PORTNUM);
}
```

6.18 autpmc_PgmOPT

This function, autpmc_PgmOPT, is for turning ON the selected output port in program mode during the set ON time at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmOPT(
  int PortNum,
  char nNodeId,
  char axis,
  int nStepNo,
  int iOnTim,
  int nOutPtNo,
  BOOL bNextStep
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.
- iOnTim
ON time for output port: 0 to 65,535ms
- nOutPtNo
Output port number(0 to 3)
- bNextStep
ON(1) : Moves to next step regardless of output operation.
OFF(0) : Turns ON the selected output port during the set ON time and moves to next step after the set time.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
    int Flag=0;

    autpmc_Open(PORTNUM, FPMC_BAUD_115200);

    Flag = autpmc_PgmOPT (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 100, 1, 1);

    if(Flag!=FPMC_OK)
    {
        printf("error!\n");
        return;
    }

    autpmc_Close(PORTNUM);
}
```

6.19 autpmc_PgmJMP

This function, autpmc_PgmJMP, is for jumping to the set step in program mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmJMP(
  int PortNum,
  char nNodeId,
  char axis,
  int nStepNo,
  int nJumpStep
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.
- nJumpStep
Step number to jump(0 to 199)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_PgmJMP (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 199);

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

6.20 autpmc_PgmREP

This function, autpmc_PgmREP, is for repeatedly running at the set times from the next step to meet autpmc_PgmRPE function(end repetitions) in program mode of PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmREP(
  int PortNum,
  char nNodeID,
  char axis,
  int nStepNo,
  int nRepCnt
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeID
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.
- nRepCnt
The number of repetitions (1 to 255)

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_PgmREP(PORTNUM, Node01, FPMC_X_AXIS, 0, 10); //Start repetitions
autpmc_PgmRPE(PORTNUM, Node01, FPMC_X_AXIS, 3); // End repetitions

if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

6.21 autpmc_PgmRPE

This function, autpmc_PgmREP, is for ending autpmc_PgmREP(start repetitions) function in program mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmRPE(
  int PortNum,
  char nNodeId,
  char axis,
  int nStepNo
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo

Enter program step number. The available range is 0 to 199.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);

  autpmc_PgmREP(PORTNUM, Node01, FPMC_X_AXIS, 0, 10); //Start repetitions

  Flag = autpmc_PgmRPE(PORTNUM, Node01, FPMC_X_AXIS, 3); // End repetitions
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

6.22 autpmc_PgmEND

This function, autpmc_PgmEND, is for ending program in program mode at PMC-2HSP/2HSN. Enter this function at the end of program.

(1) Syntax

```
int autpmc_PgmEND(
int PortNum,
char nNodeId,
char axis,
int nStepNo
);
```

(2) Parameter

- PortNum

Enter serial port to execute the command.

- nNodeId

Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.

- axis

Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo

Enter program step number. The available range is 0 to 199.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_PgmEND(PORTNUM, Node01, FPMC_X_Y_AXIS, 0);
```

```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

6.23 autpmc_PgmTIM

This function, autpmc_PgmTIM, is for executing wait command during the set time in program mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmTIM(
  int PortNum,
  char nNodeId,
  char axis,
  int nStepNo,
  int nOnTim
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.
- nOnTim
Enter wait time. The available range is 0 to 65,535ms.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
  int Flag=0;

  autpmc_Open(PORTNUM, FPMC_BAUD_115200);
```

```
Flag = autpmc_PgmTIM (PORTNUM, Node01, FPMC_X_Y_AXIS, 0, 100);  
  
if(Flag!=FPMC_OK)  
{  
    printf("error!\n");  
    return;  
}  
  
autpmc_Close(PORTNUM);  
}
```

6.24 autpmc_PgmNOP

This function, autpmc_PgmNOP, is for none in program mode at PMC-2HSP/2HSN.

(1) Syntax

```
int autpmc_PgmNOP(
int PortNum,
char nNodeId,
char axis,
int nStepNo
);
```

(2) Parameter

- PortNum
Enter serial port to execute the command.
- nNodeId
Select the node ID. The range of node ID is 1 to 16. FPMC_INVALID_NODE(3) is returned when the node ID is out of the range.
- axis
Select the control axis (X-axis, Y-axis). FPMC_INVALID_AXIS(4) is returned when entering the invalid axis.

Item	Definition	Description	Constant value
PMC_AXIS	FPMC_X_AXIS	X-axis	0
	FPMC_Y_AXIS	Y-axis	1
	FPMC_X_Y_AXIS	X, Y-axis	2

- nStepNo
Enter program step number. The available range is 0 to 199.

(3) Return value

Item	Definition	Return value	Description
Normal	FPMC_OK	0	The command is normally executed.
Input error	FPMC_INVALID_NODE	3	Invalid node ID is entered.
	FPMC_INVALID_AXIS	4	Invalid axis is entered.
	FPMC_INVALID_DATA	5	Invalid data is entered.

(4) Example

```
#include <stdio.h>
#include <windows.h>
#include "Library.h"

#define PORTNUM 3

void main()
{
int Flag=0;

autpmc_Open(PORTNUM, FPMC_BAUD_115200);

Flag = autpmc_PgmNOP(PORTNUM, Node01, FPMC_X_Y_AXIS, 190);
```


```
if(Flag!=FPMC_OK)
{
    printf("error!\n");
    return;
}

autpmc_Close(PORTNUM);
}
```

7 Example Of MFC Program For Using Library

(1) Example of MFC program

This is example of MFC program by using library function. You can check the sources and it helps to understand necessary operations to use.



(2) Descriptions

No.	Item	Description
①	Port Connection	Calls the port connecton library function and connects/disconnects communication. .
②	Reset Motion IC	Resets the connected PMC motion IC.
③	Home Search	Calls home search library function and runs/stops home search.
④	State Check	Checks the connected PMC motion driver stauts or error. (It is available to check running state or error of home search mode, jog mode, program mode of each axis)
⑤	Properties	Reads/Writes the set parameter value of PMC motion driver.
⑥	Manual Mode	This mode executes one drive sending packet by communication.
⑦	Program Mode	This mode is for executing the set continuous drive on EEPROM at the disconnected environment.
⑧	Log	Check the library syntacx and detailed properties about the executed functions.

Autonics

Sensors & Controllers

Distributor



Major products

- Photoelectric sensors • Fiber optic sensors • Door sensors • Door side sensors • Area sensors
- Proximity sensors • Pressure sensors • Rotary encoders • Connector/sockets
- Switching mode power supplies • Control switches/Lamps/Buzzers • Temperature controllers
- Temperature/Humidity transducers • SSR/Power controllers • Counters • Timers • Panel meters
- Tachometer/Pulse(Rate) meters • Display units • Sensor controllers
- I/O Terminal Blocks & Cables • Stepper motors/drivers/motion controllers
- Graphic/Logic panels • Field network devices • Laser marking system(Fiber, CO₂, Nd:YAG)
- Laser welding/soldering system

Any proposal for a product improvement and development: Product@autonics.com

www.autonics.com

Headquarters

18, Bansong-ro 513beon-gil, Haeundae-gu, Busan, South Korea

Overseas Business Headquarters

#402-404, Bucheon Techno Park, 655, Pyeongcheon-ro, Wonmi-gu, Bucheon, Gyeonggi-do, Korea
Tel: 82-32-610-2730 / Fax: 82-32-329-0728 / E-mail: sales@autonics.com

Brazil Autonics do Brasil Comercial Importadora Exportadora Ltda

Rua Dr. Licinio Maragliano, 369 Santo Amaro - Sao Paulo - SP - CEP: 04753-130, Brazil
Tel: 55-11-2307-8480 / Fax: 55-11-2309-7784 / E-mail: vendas@autonics.com.br

China Autonics electronic(Jiaxing) Corporation

#301 YUN HAI ROAD jiaxing, Zhejiang, China, 314001
Tel: 86-21-5422-5869 / Fax: 86-21-5422-5961 / E-mail: china@autonics.com

India Autonics Automation India Private Limited

Fantasia Business Park Unit No- G 174 & 175, Plot No.47, Sector 30A, Vashi, Navi Mumbai, India 400 703.
Tel: 91-22-2781-4305 / Fax: 91-22-2781-4518 / E-mail: india@autonics.com

Indonesia PT. Autonics Indonesia

Jl.Dewi Sartika No. 171, Jakarta Timur
Tel: 62-21-8088-8815 / Fax: 62-21-8088-4440 / E-mail: indonesia@autonics.com

Japan Autonics Japan Corporation

645-1, MIKKAMACHI, MINOWA-MACHI, KAMINA-GUN, NAGANO-KEN 399-4603 JAPAN
Tel: 81-265-79-8570 / Fax: 81-265-79-2442 / E-mail: support@autonicsjp.co.jp

Malaysia Mal-Autonics Sensor Sdn. Bhd.

Unit No 613 & 614, Block A, Kelana Business Centre 97, Jalan SS7/2, Kelana Jaya, 47301 Petaling Jaya, Selangor Malaysia.
Tel: 60-3-7805-7190(Hunting) / Fax: 60-3-7805-7193 / E-mail: malaysia@autonics.com

Mexico Autonics Mexico S.A. DE C.V

Av. Doctor Gustavo Baz Prada no. 98 Int. 7ºFracc. Industrial Alce Blanco, Naucalpan de Juarez, Estado de Mexico C.P. 53370
Tel: 52-55-5207-0019 / Fax: 52-55-1663-0712 / E-mail: informes@autonics.com

Russia Autonics Corp. Russia Representative Office

Office 2008, entrance "B", section 3, str. Ul'fa Palms, 1, Moscow, 119590, Russia
Tel/Fax: 7-495-660-10-88 / E-mail: russia@autonics.com

Turkey Autonics Otomasyon Ticaret Ltd. Sti.

Serifali Mh. Turker Cd. Burhan Sk. No:23 Kat:2 Umranije, Istanbul, Turkey
Tel: 90-216-365-9117(9113, 9114) / Fax: 90-216-365-9112 / E-mail: info@autonics.com.tr

USA Autonics USA, Inc.

1353 Armour Blvd, Mundelein, IL 60060, USA
Tel: 1-847-680-8160 / Fax: 1-847-680-8155 / E-mail: sales@autonicsusa.net

Vietnam Cong Ty Tnhh Autonics Vina

Nguyen Hung Phu Office Building, No.400 Nguyen Thi Thap Street, Tan Quy Ward, District 7, Ho Chi Minh City, Vietnam
Tel: 84-8-3771-2662 / Fax: 84-8-3771-2663 / E-mail: vietnam@autonics.com