

Multi-CH Modular Type Temperature Controller

# TM-Q02H(RS485)

## Technical Support Manual



TM Series



# Preface

Thank you very much for selecting Autonics products.





Please familiarize yourself with the information contained in the **Safety Precautions** section before using this product.

This user manual contains information about the product and its proper use, and should be kept in a place where it will be easy to access.

# Technical Support Manual Guide


- Please familiarize yourself with the information in this manual before using the product.
- This manual provides detailed information on the product's features. It does not offer any guarantee concerning matters beyond the scope of this manual.
- This manual may not be edited or reproduced in either part or whole without permission.
- This manual is not provided as part of the product package. Please visit our home-page ([www.autonics.com](http://www.autonics.com)) to download a copy.
- The manual's content may vary depending on changes to the product's software and other unforeseen developments within Autonics, and is subject to change without prior notice. Upgrade notice is provided through our homepage.
- We contrived to describe this manual more easily and correctly. However, if there are any corrections or questions, please notify us these on our homepage.


# Technical Support Manual Symbols

| Symbol   | Description  |
|--|--|
|  <b>Note</b>    | Supplementary information for a particular feature.                          |
|  <b>Warning</b> | Failure to follow instructions can result in serious injury or death.        |
|  <b>Caution</b> | Failure to follow instructions can lead to a minor injury or product damage. |
|  <b>Ex.</b>     | An example of the concerned feature's use.                                   |
| ※1   | Annotation mark.   |

# Safety Precautions

- Following these safety precautions will ensure the safe and proper use of the product and help prevent accidents, as well as minimizing possible hazards.
- Safety precautions are categorized as Warnings and Cautions, as defined below:

|  |                |  |
|--|----------------|--|
|  <b>Warning</b> | <b>Warning</b> | Failure to follow the instructions may lead to a serious injury or accident. |
|--|----------------|--|

|  |                |  |
|--|----------------|--|
|  <b>Caution</b> | <b>Caution</b> | Failure to follow the instructions may lead to a minor injury or accident. |
|--|----------------|--|

## Warning

- Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.)  
Failure to follow this instruction may result in personal injury, fire, or economic loss.
- The unit must be installed on a device panel before use.  
Failure to follow this instruction may result in electric shock.
- Do not connect, repair, or inspect the unit while connected to a power source.  
Failure to follow this instruction may result in electric shock.
- Check the input power specifications and terminal polarity for correct connecting the power source.  
Failure to follow this instruction may result in fire.
- Do not disassemble or modify the unit. Please contact us if necessary.  
Failure to follow this instruction may result in electric shock or fire.

## Caution

- Do not use the unit outdoors.  
Failure to follow this instruction may result in shortening the life cycle of the unit, or electric shock.
- When connecting the power input and relay output cables, use AWG20 (0.5mm<sup>2</sup>) cables.  
Failure to follow this instruction may result in fire due to contact failure.
- Use the unit within the rated specifications.  
Failure to follow this instruction may result in shortening the life cycle of the unit, or fire.
- Do not use loads beyond the rated switching capacity of the relay contact.  
Do not use water or oil-based detergent when cleaning the unit. Use dry cloth to clean the unit.
- Do not use water or oil-based detergent when cleaning the unit. Use dry cloth to clean the unit.  
Failure to follow this instruction may result in electric shock or fire.

- Do not use the unit where flammable or explosive gas, humidity, direct sunlight, radiant heat, vibration, or impact may be present.  
Failure to follow this instruction may result in fire or explosion.
- Keep dust and wire residue from flowing into the unit.  
Failure to follow this instruction may result in fire or product damage.
- Check the polarity of the measurement input contact before wiring the temperature sensor.  
Failure to follow this instruction may result in fire or explosion.
- For installing the unit with reinforced insulation, use the power supply unit which basic level is ensured.





# Table of Contents

|  |           |
|--|-----------|
| Preface .....  | 5         |
| Technical Support Manual Guide .....                           | 6         |
| Technical Support Manual Symbols .....                         | 7         |
| Safety Precautions .....                                       | 8         |
| Table of Contents .....  | 11        |
| <b>1 System .....</b>  | <b>13</b> |
| 1.1 Version .....  | 13        |
| 1.2 Connections .....  | 13        |
| 1.3 Communication cable connection .....                       | 13        |
| 1.4 Communication connection and multi module connection ..... | 14        |
| <b>2 Communication Setting .....</b>                           | <b>15</b> |
| 2.1 TM4 Series Setting .....                                   | 15        |
| 2.2 GX-Works2 Setting (Network) .....                          | 16        |
| 2.3 GX-Works2 Program .....                                    | 25        |




# 1 System

## 1.1 Version

| Software   | Version   | Note                 |
|------------|-----------|----------------------|
| Operations | Windows 7 | —                    |
| GX Works2  | 1.545T    | Release : 2016.03.29 |


## 1.2 Connections



## 1.3 Communication cable connection

| TM4 Series   | Cable connection | PLC (QJ71C24N) |
|--------------|------------------|----------------|
| RS - 485 (-) |                  | SDB            |
|              |                  | SDA            |
| RS - 485 (+) |                  | RDB            |
|              |                  | RDA            |


## 1.4 Communication connection and multi module connection



When using the port A, only single module is available.

For using single/multi module, use the port B.

### • Multi module connection



## 2 Communication Setting

### 2.1 TM4 Series Setting

1st TM4 is multi-channel temperature controller. You can set the parameter settings by DAQMaster, the dedicated comprehensive device management program. (address setting is available to adjust by the communication address setting switch (SW1), communication address group switch (SW2) of the unit)

2nd Indicators for initial power ON

| Indicator   | Status | Initial power ON | Control output | Auto-tuning |
|-------------|--------|------------------|----------------|-------------|
| PWR (green) |        | ON               | ON             | ON          |
| CH1 (red)   |        | Flash (2400bps)  | ON             | Flash       |
| CH2 (red)   |        | Flash (4800bps)  | ON             | Flash       |
| CH3 (red)   |        | Flash (9600bps)  | ON             | Flash       |
| CH4 (red)   |        | Flash (19200bps) | ON             | Flash       |
|             |        | Flash (38400bps) | -              | -           |

\* When power is supplied initially, the set communication speed LED flashes for 5 sec.

\* The auto-tuning CH LED flashes for 1 sec in turn.

\* The PWR LED flashes during communication for 1 sec in turn.



3rd Communication settings are available at Communication Setting of at DAQMaster.




| Item                  | Setting | Note         |
|-----------------------|---------|--------------|
| Baudrate              | 38400   | Same as PLC  |
| Parity Bit            | None    | Same as PLC  |
| Stop Bit              | 2       | Same as PLC  |
| Response Waiting Time | 20      | User setting |
| Communication Write   | Enable  | Fixed        |

## 2.2 GX-Works2 Setting (Network)


1st Add I/F Module as “QJ71C24N” and set communication setting at “Switch setting”.



2nd Run [Tool - intelligent Function Module Tool – Serial Communication Module – Predefined Protocol Support Function] on menu.




3rd Enter present value (PV) reading protocol and setting value (SV) writing protocol.



4th Packet setting

▶ PV reading transmitting/receiving protocol: 04. RD IN Registers Setting

<Send. 04:RD IN Registers Packet Setting>



| Element No. | Element Name                | Setting | Note                      |
|-------------|-----------------------------|---------|---------------------------|
| 1           | Slave Address               | D500    | Target address (device)   |
| 2           | Function Code               | 04(HEX) | Function Code             |
| 3           | Starting Address            | D501    | Start address (memory)    |
| 4           | Quantity of Input Registers | D502    | No. of requested readings |
| 5           | Error Check                 | Fixed   | CRC16                     |

E.g.) When reading 2 values within Input Register 301001(03E8 H) to 301002(03E9 H) of Slave(address 1) at Master,

| Slave Address | Function | Starting Address |     | No. of Points |     | Error Check(CRC16) |      |
|---------------|----------|------------------|-----|---------------|-----|--------------------|------|
|               |          | High             | Low | High          | Low | Low                | High |
| 01H           | 04H      | 03H              | E8H | 00H           | 02H | F1 H               | BB H |



<Receive(1). NOR / 04:RD IN Registers Packet Setting >

| Element No. | Element Type            | Element Name    | Element Setting  |
|-------------|-------------------------|-----------------|--|
| 1           | Non-conversion Variable | Slave Address   | [D510-D510](Fixed Length/1Byte/Lower/Upper Byte/No Swap)           |
| 2           | Static Data             | Function Code   | 04(1Byte)  |
| 3           | Length                  | Byte Count      | (Object element4-4/HEX/1Byte)                                      |
| 4           | Non-conversion Variable | Input Registers | [D999][D1000-D1124](Variable Length/250Byte/Lower/Upper Byte/Swap) |
| 5           | Check Code              | Error Check     | (Object element1-4/CRC MOD)  |


| Element No. | Element Name    | Setting | Note                    |
|-------------|-----------------|---------|-------------------------|
| 1           | Slave Address   | D510    | Target address (device) |
| 2           | Function Code   | 04(HEX) | Function Code           |
| 3           | Byte Count      | Fixed   | No. of received byte    |
| 4           | Input Registers | D999    | Data length             |
|             |                 | D1000   | Received data           |
| 5           | Error Check     | Fixed   | CRC16                   |

E.g.) When 301001(03E8 H) value of Slave(address 1) is "10" and 301002(03E9 H) value is "20",

| Slave Address | Function | Byte Count | Data |      | Data |      | Error Check(CRC16) |      |
|---------------|----------|------------|------|------|------|------|--------------------|------|
|               |          |            | High | Low  | High | Low  | Low                | High |
| 01 H          | 04 H     | 04 H       | 00 H | 0A H | 00 H | 14 H | DB H               | 89 H |

←----- CRC16 ----->

<Receive(2). ERR / 04:RD IN Registers Packet Setting >



| Element No. | Element Name   | Setting | Note                    |
|-------------|----------------|---------|-------------------------|
| 1           | Slave Address  | D520    | Target address (device) |
| 2           | Error Code     | 84(HEX) | Error Code              |
| 3           | Exception Code | D1125   | Error content           |
| 4           | Error Check    | Fixed   | CRC16                   |

\* Exception Response - Error code

| Code number | Error                | Description  |
|-------------|----------------------|--|
| 01 H        | ILLEGAL FUNCTION     | Not supported command.   |
| 02 H        | ILLEGAL DATA ADDRESS | Starting Address of the queried data is inconsistent with transmittable address from the device. |
| 03 H        | ILLEGAL DATA VALUE   | Numbers of queried data are inconsistent with the numbers of transferable data from device.      |
| 04 H        | SLAVE DEVICE FAILURE | Not properly complete the queried command.   |


E.g.) Output status response of the not-exist coil 01001(03E8 H) about address 1

| Slave Address | Function +80 H | Exception Code | Error Check(CRC16) |      |
|---------------|----------------|----------------|--------------------|------|
|               |                |                | Low                | High |
| 01 H          | 81 H           | 02 H           | C1                 | 91   |



As the above table, the response of Exception Code is 02H.

► SV reading transmit/receive protocol: 06. WR Single Register  
 <Send. 06:WR Single Register Packet Setting>



| Element No. | Element Name     | Setting | Note                    |
|-------------|------------------|---------|-------------------------|
| 1           | Slave Address    | D503    | Target address (device) |
| 2           | Function Code    | 06(HEX) | Function Code           |
| 3           | Register Address | D504    | Target address (memory) |
| 4           | Register Value   | D1500   | Write data              |
| 5           | Error Check      | Fixed   | CRC16                   |

E.g.) When writing "10" on Holding Register 400001(0000 H) of Slave(address 1) at Master,

| Slave Address | Function | Register Address |      | Preset Data |      | Error Check(CRC16) |      |
|---------------|----------|------------------|------|-------------|------|--------------------|------|
|               |          | High             | Low  | High        | Low  | Low                | High |
| 01 H          | 06 H     | 00 H             | 00 H | 00 H        | 0A H | 09 H               | CD H |

←----- CRC16 ----->

<Receive(1). NOR / 06:WR Single Register Packet Setting>

| Element No. | Element Type            | Element Name     | Element Setting  |
|-------------|-------------------------|------------------|--|
| 1           | Non-conversion Variable | Slave Address    | [D530-D530](Fixed Length/1Byte/Lower/Upper Byte/No Swap) |
| 2           | Static Data             | Function Code    | 06(1Byte)  |
| 3           | Non-conversion Variable | Register Address | [D531-D531](Fixed Length/2Byte/Lower/Upper Byte/Swap)    |
| 4           | Non-conversion Variable | Register Value   | [D532-D532](Fixed Length/2Byte/Lower/Upper Byte/Swap)    |
| 5           | Check Code              | Error Check      | (Object element 1-4/CRC MOD)                             |

| Element No. | Element Name     | Setting | Note                    |
|-------------|------------------|---------|-------------------------|
| 1           | Slave Address    | D530    | Target address (device) |
| 2           | Function Code    | 06(HEX) | Function Code           |
| 3           | Register Address | D531    | Target address (memory) |
| 4           | Register Value   | D532    | Write data              |
| 5           | Error Check      | Fixed   | CRC16                   |


When single writing (F/C 06) is completed normally, the received response packet from low device is same as the transmit packet of Master device.

E.g.) When writing "10" on Holding Register 40001(0000 H) of Slave(address 1) at Master,

| Slave Address | Function | Register Address |      | Preset Data |      | Error Check(CRC16) |      |
|---------------|----------|------------------|------|-------------|------|--------------------|------|
|               |          | High             | Low  | High        | Low  | Low                | High |
| 01 H          | 06 H     | 00 H             | 00 H | 00 H        | 0A H | 09 H               | CD H |

←————— CRC16 —————→

<Receive(2). ERR / 06:WR Single Register Packet Setting >



| Element No. | Element Name   | Setting | Note                    |
|-------------|----------------|---------|-------------------------|
| 1           | Slave Address  | D540    | Target address (device) |
| 2           | Error Code     | 86(HEX) | Error Code              |
| 3           | Exception Code | D1126   | Error content           |
| 4           | Error Check    | Fixed   | CRC16                   |

\* Exception Response - Error code

| Code number | Error name           | Description  |
|-------------|----------------------|--|
| 01 H        | ILLEGAL FUNCTION     | Not supported command.   |
| 02 H        | ILLEGAL DATA ADDRESS | Starting Address of the queried data is inconsistent with transmittable address from the device. |
| 03 H        | ILLEGAL DATA VALUE   | Numbers of queried data are inconsistent with the numbers of transferable data from device.      |
| 04 H        | SLAVE DEVICE FAILURE | Not properly complete the queried command.   |


E.g.) Output status response of the not-exist coil 01001(03E8 H) about address 1

| Slave Address | Function +80 H | Exception Code | Error Check(CRC16) |      |
|---------------|----------------|----------------|--------------------|------|
|               |                |                | Low                | High |
| 01 H          | 81 H           | 02 H           | C1                 | 91   |



As the above table, the response of Exception Code is 02H.

5th Download the set protocol setting on [Module Read/Write – write to Module].



### 2.3 GX-Works2 Program


1st The order of communication program is as below.

[Requests reading address 1 CH1 to CH4\_PV]→[Receiving address 1 CH1\_PV]→[Receiving address 1 CH2\_PV]→ ... →[Requests reading address 2 CH1 to CH4\_PV]→[Receiving address 2 CH1\_PV]→[Receiving address 2 CH2\_PV]  
(repeat continuously)


※ Requests writing SV: occurs one time when SV Trigger is on.

E.g.) M1200 : [#1 CH1\_SV] → M1201 : [#1 CH2\_SV] → M1202 [#1 CH3\_SV] → ...  
M1204 : [#2 CH1\_SV] → ... → M1207 : [#2 CH4\_SV]


2nd PV reading program



3rd SV writing program








# Autonics

Sensors & Controllers

www.autonics.com

## Distributor



### Major Products

·Photoelectric Sensors·Fiber Optic Sensors·Door Sensors·Door Side Sensors·Area Sensors  
·Proximity Sensors·Pressure Sensors·Connectors·Sockets·Rotary Encoders·Panel Meters  
·Counters·Timers·Temperature Controllers·SSRs·Power Controllers·Sensor Controllers  
·Graphic/Logic Panels·Temperature/Humidity Transducers·Switching Mode Power Supplies  
·Stepper Motors·Drivers·Motion Controllers·I/O Terminal Blocks & Cables·Display Units  
·Control Switches/Lamps/Buzzers·Field Network Devices·Tachometer/Pulse(Rate) Meters  
·Laser Marking System(Fiber, CO<sub>2</sub>, Nd:YAG)·Laser Welding/Cutting System

■ Any proposal for a product improvement and development: [Product@autonics.com](mailto:Product@autonics.com)

### Corporate Headquarters

18 Bansong-ro, 513 Beon-gil, Haeundae-gu, Busan, South Korea 48002

### Overseas Business Headquarters

#402-303, Bucheon Techno Park, 655, Pyeongcheon-ro, Wonmi-gu, Bucheon, Gyeonggi-do, South Korea 14502

Tel: 82-32-610-2730 / Fax: 82-32-329-0728 / E-mail: [sales@autonics.com](mailto:sales@autonics.com)

### Brazil – Autonics do Brasil Comercial Importadora Exportadora Ltda

Tel: 55-11-2307-8480 / Fax: 55-11-2309-7784 / E-mail: [comercial@autonics.com.br](mailto:comercial@autonics.com.br)

### China – Autonics electronic(JiXing) Corporation

Tel: 86-21-5422-5969 / Fax: 86-21-5422-5961 / E-mail: [china@autonics.com](mailto:china@autonics.com)

### India – Autonics Automation India Private Limited

Tel: 91-22-2781-4305 / Fax: 91-22-2781-4518 / E-mail: [india@autonics.com](mailto:india@autonics.com)

### Indonesia – PT. Autonics Indonesia

Tel: 62-21-8088-8814/5 / Fax: 62-21-8088-4442(4440) / E-mail: [indonesia@autonics.com](mailto:indonesia@autonics.com)

### Japan – Autonics Japan Corporation

Tel: 81-3-3950-3111 / Fax: 81-3-3950-3191 / E-mail: [ja@autonics.com](mailto:ja@autonics.com)

### Malaysia – Mal-Autonics Sensor Sdn. Bhd.

Tel: 60-3-7805-7190 / Fax: 60-3-7805-7193 / E-mail: [malaysia@autonics.com](mailto:malaysia@autonics.com)

### Mexico – Autonics Mexico S.A. DE C.V

Tel: 52-55-5207-0019 / Fax: 52-55-1663-0712 / E-mail: [ventas@autonics.com](mailto:ventas@autonics.com)

### Russia – Autonics Corp. Russia Representative Office

Tel/Fax: 7-495-660-10-88 / E-mail: [russia@autonics.com](mailto:russia@autonics.com)

### Turkey – Autonics Otomasyon Ticaret Ltd. Sti.

Tel: 90-216-365-9117/3/4 / Fax: 90-216-365-9112 / E-mail: [infotr@autonics.com](mailto:infotr@autonics.com)

### USA – Autonics USA, Inc.

Tel: 1-847-680-8160 / Fax: 1-847-680-8155 / E-mail: [sales@autonicsusa.net](mailto:sales@autonicsusa.net)

### Vietnam – Cong Ty TNHH Autonics Vina

Tel: 84-8-3771-2662 / Fax: 84-8-3771-2663 / E-mail: [vietnam@autonics.com](mailto:vietnam@autonics.com)