

Autonics

INTELLIGENT DISPLAY UNIT (RS485 Synchronous Communication Type for Time Display) DS-C Series INSTRUCTION MANUAL



Thank you for choosing our Autonics products.
Please read the following safety considerations before use.

■ Safety Considerations

※Please observe all safety considerations for safe and proper product operation to avoid hazards.

- ※Safety considerations are categorized as follows.
⚠Warning Failure to follow these instructions may result in serious injury or death.
⚠Caution Failure to follow these instructions may result in personal injury or product damage.

※The symbols used on the product and instruction manual represent the following
⚠ symbol represents caution due to special circumstances in which hazards may occur.

- ⚠Warning
1. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss.
2. Install on a device panel to use.
3. Do not connect, repair, or inspect the unit while connected to a power source.
4. Check 'Unit description and function setting' before wiring.
5. Do not disassemble or modify the unit.

- ⚠Caution
1. Use the unit within the rated specifications.
2. Use dry cloth to clean the unit, and do not use water or organic solvent.
3. Do not use the unit in the place where flammable/explosive/corrosive gas, humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
4. Keep metal chip, dust, and wire residue from flowing into the unit.

■ Model


Table with 3 columns: Model, Display method, Size. Rows include DS22-C, DS40-C, and DS60-C.

Table with 6 columns: Model, Display method, Size, Model, Display method, Size. Rows include DS22-E, DS40-E, and DS60-E.

※1: Use 16 Segment expansion unit for displaying delimiter for hour/min./sec. and 'M' character for AM/PM.
※□ indicates color: R(Red), G(Green)

■ Remove of Protection Cover

To operate the function set switch of the DS40, DS60 models, you should remove the protection cover. Press the connection parts (4 points) of the protection cover at the top/bottom of the product with a flat-head screwdriver and the protection cover is removed.



⚠Caution: Before removing the protection cover, power must be turned OFF.

■ Device Synchronized Time Transfer Program [World Clock]

World Clock is time synchronization program for DS-C Series. You can check the desired world time zone or set summer time. For more information, please refer to the World Clock user manual. Visit our website (www.autonics.com) to download World Clock.

Table with 2 columns: Item, Minimum specifications. Lists system requirements like computer, memory, hard disk, etc.

※The above specifications are subject to change and some models may be discontinued without notice.
※Be sure to follow cautions written in the instruction manual and the technical descriptions (catalog, homepage).

■ Specifications


Main specification table with columns for Model, Input method, Display color, Power supply, etc., and rows for Basic unit, Expansion unit, and DS22-C, DS40-C, DS60-C.

※1: The weight includes packaging. The weight in parentheses is for unit only.
※2: This is 3 units' weight as packaging unit and the weight in parentheses is only unit weight.


RS485 communication specifications table with columns for Comm. protocol, Connection type, Application standard, etc.

■ Dimensions


1) DS22 (unit: mm). Dimensions and panel cut-out details for the DS22 model.




2) DS40 (unit: mm). Dimensions and panel cut-out details for the DS40 model.



3) DS60 (unit: mm). Dimensions and panel cut-out details for the DS60 model.






4) Accessory. Lists components: D-22, D-40/D-60, D-22, Cap, Connector, Ribbon cable (50mm), BK-D22R.



■ Unit Description and Function Setting

Only the basic unit model has the function set switch and the input terminal. The DS22 models have them at the side, and the DS40, DS60 models have them at the rear.

⊖Expansion connector Using for connecting units. Refer to 'Connection of units'.



World Time Zone selection table with columns for No., Code, Function, and details for UTC time zones and RS485 B (-).

■ World Time Zone

※Select the desired world time zone by function set switches (J1 to J16).
※If communication is not connected when supplying the power, the unit displays the set local time zone.



World Time Zone selection table with columns for No., Switch (OFF/ON), Time Zone, and Location.

■ Display Example of Delimiter For Hour/Min./Sec.

Table showing display examples for hour/min./sec. and 12-hour time with and without a delimiter.


※Use 16 Segment expansion unit for 'M' character for AM/PM when displaying 12 hours time.

■ Connection of Units



※You can use both the 7 segment model and the 16 segment model mixed.

■ Communication Setting



※It is recommended to use Autonics communication converter: SCM-WF48 (Wi-Fi to RS485-USB wireless communication converter, sold separately), SCM-US48I (USB to RS485 converter, sold separately), SCM-38I (RS232C to RS485 converter, sold separately). Please use twist pair wire for RS485 communication.

Modbus Address Mapping table with columns for No./Address, Func, R/W, Description, and Setting range.

■ Cautions during Use

- 1. Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
2. 12-24VDC power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
3. Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
4. Keep away from high voltage lines or power lines to prevent inductive noise.
5. This unit may be used in the following environments.

■ Major Products

List of major products including Photoelectric Sensors, Fiber Optic Sensors, Door Sensors, Area Sensors, etc., and Autonics Corporation contact information (HQ, TEL, E-mail).