



Parameter Group




※If there is no key input for 30 sec while setting SV or the parameters, the new settings are ignored, and the unit will return to RUN mode with previous settings.
 ※Hold the **MODE** key for 3 sec while in setting mode to return to RUN mode.


Monitoring group



Parameter 1 group



Parameter 2 group



Functions

Output limit (OUT ADJ)

This function will be [Control input (%) × OUT ADJ (%) = Output] and it controls the power supplied into the load. Although control input is 100% (5V or 20mA), the output is the 50% which is proportioned with OUT ADJ.

※This function can not be used for ON/OFF control method.

Output high limit/low limit value [H-L / L-L]

This function is to limit output range to protect load.

SOFT START [S-t]

When the power is supplied, this function is able to protect the load when it controls load (molybdenum, white gold, infrared lamp) with inrush current or the width of rising temperature in big (SV is big).

SOFT START set time (T) is the required time that output reaches to 100%, and it is differentiated by OUT ADJ set value.

※This function can not be used for ON/OFF control method.

SOFT UP/DOWN [U-t / d-t]

Unlike SOFT START which operates only once at supplying power, this function protects load from the inrush current in the RUN mode. When reached to the target output value, operation stops.

※This function can not be used for ON/OFF control method.

Input correction [I-nb]

It compensates the offset between actual input value and measured input value.

E.g.) When input monitoring value is 5% at 4mA in DC4-20mA control input, setting I-nb to -5 calibrates the input monitoring value to 0%.

Input slope correction [SPn]

It compensates the gain of the measured 100% input for actual 100% input value.

E.g.) When the input monitoring value is 99% at 4mA in DC4-20mA control input, setting SPn to 1 calibrates the input monitoring value to 100%.

RUN/STOP switching

RUN/STOP status of the power controller can be switched with the external RUN/STOP contact. In the RUN mode, the operation indicator on the front turns on.

AUTO/MANUAL selection

Operation mode (auto control/manual control) of the power controller can be selected with the external AUTO/MAN contact. In the manual control mode, the manual control indicator on the front turns on.

RESET

In the event of system anomalies and alarms, RESET input restarts the power controller. (Parameters are not initialized.) Or, hold the **MODE** key for 2 sec, to operate RESET.

Alarm

Type	Error	Operation	Clear alarm	Display priority
SCR error alarm ^{※1}	SCr			1
Overcurrent alarm ^{※1}	o-c	Output stops. (SCR OFF)	- Re-supply the power. - RESET	2
Fuse break alarm	FUS		- Switch to STOP mode	3
Heatsink overheat alarm	HEH			4
Overvoltage alarm ^{※1}	o-v			5
Heater break alarm ^{※1}	H-b	Continues operation	Automatically cleared when returning within the setting range.	6

※1: This is only for feedback control models.
 ※For models with alarm output, the error message and alarm indicator flash at the same time, and alarm output turns on.
 ※When multiple alarms occur at the same time, the highest priority error message will be displayed based on priority.

1) SCR error alarm

Even though output is 0%, if the current of 10% or more of the rated load current flows for over 3 sec continuously, SCR error alarm occurs and output stops.

2) Overcurrent alarm [o-c / o-c-t]

This function protects the load from overcurrent. If the current flows over the overcurrent alarm setting value and setting delay time, overcurrent alarm occurs and output stops.

3) Heatsink overheat alarm

When the temperature of a heatsink is over 85°C, heatsink overheat alarm occurs and output stops.

4) Overvoltage alarm [o-v / o-v-t]

This function protects the load from overvoltage. If the current flows over the overvoltage alarm setting value and setting delay time, overvoltage alarm occurs and output stops.

5) Heater break alarm [H-b / H-b-t]

Comparing the full load resistance value and the current load resistance value, if the current load resistivity is maintained under the setting value for over 3 sec continuously, heater break alarm occurs. Output does not stop and operates normally.


Current load resistivity(%) = $\frac{\text{Full load resistance value}}{\text{Current load resistance value}} \times 100$

Cautions during Use


- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- Use the product, after 3 sec of supplying power.
- Before use, set the mode and function according to the specification. Especially, be cautious that the product does not operate when OUT ADJ. is set to 0%. Since changing the mode/parameter during operation may result in malfunction, set the mode and function after disconnecting load output.
- Re-supply the power to the unit after the unit is discharged completely. Failure to follow this instruction may result in malfunction.
- To ensure the reliability of the product, install the product on the panel or metal surface vertically to the ground.
- Install the unit in the well ventilated place.
- While supplying power to the load or right after turning off the power of the load, do not touch the body and heat sink. Failure to follow this instruction may result in a burn due to the high temperature.
- Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
- Do not wire to terminals which are not used.
- Since inter element can be damaged when using with coil load, inductive load, etc., the inrush current must be under the rated load current.
- Do not use near the equipment which generates strong magnetic force or high frequency noise.
- This unit may be used in the following environments.
 - Indoors (in the environment condition rated in 'Specifications')
 - Altitude max. 2,000m
 - Pollution degree 2
 - Installation category III

Derating Curve


Rated load current 25A




Rated load current 35A




Rated load current 50A




Rated load current 70A



Rated load current 100A



Rated load current 150A



Comprehensive Device Management Program [DAQMaster]

DAQMaster is a comprehensive device management software for setting parameters and monitoring processes. DAQMaster can be downloaded from our website at www.autonics.com.

Item	Minimum specifications
System	IBM PC compatible computer with Pentium III or above
Operations	Windows 98/NT/XP/Vista/7/8/10
Memory	256MB+
Hard disk	1GB+ of available hard disk space
VGA	Resolution: 1024×768 or higher
Others	RS232C serial port (9-pin), USB port

User Manual for Communication

For the detail information and instructions, please refer to user manual for communication, and be sure to follow cautions written in the technical descriptions (catalog, homepage). Visit our homepage (www.autonics.com) to download manuals.


RS485 Communication Output

※Applicable for models with RS485 communication output through option output (SPR3-□□□□□). Please refer to 'Ordering Information'.

1. Communication Specifications

Comm. protocol	Modbus RTU	Comm. speed	2400, 4800, 9600, 19200, 38400 bps
Connection method	RS485	Comm. response time	5 to 99ms (default: 20ms)
Application standard	Compliance with EIA RS485	Start bit	1-bit (fixed)
Max. connections	31 units (address: 1 to 99)	Data bit	8-bit (fixed)
Synchronization method	Asynchronous	Parity bit	None, Even, Odd
Comm. method	Two-wire half duplex	Stop bit	1-bit, 2-bit
Comm. distance	Max. 800m		

2. Application of system organization



※It is recommended to use Autonics communication converter; SCM-WF48 (Wi-Fi to RS485-USB wireless communication converter, sold separately), SCM-US48l (USB to RS485 converter, sold separately), SCM-38l (RS232C to RS485 converter, sold separately). Please use twisted pair wire, which is suitable for RS485 communication, for SCM-WF48, SCM-US48l and SCM-38l.

Major Products

- Photoelectric Sensors
- Fiber Optic Sensors
- Door Sensors
- Door Side Sensors
- Area Sensors
- Proximity Sensors
- Pressure Sensors
- Rotary Encoders
- Connector/Sockets
- Switching Mode Power Supplies
- Control Switches/Lamps/Buzzers
- I/O Terminal Blocks & Cables
- Stepper Motors/Drivers/Motion Controllers
- Graphic/Logic Panels
- Field Network Devices
- Laser Marking System (Fiber, CO₂, Nd: YAG)
- Laser Welding/Cutting System
- Temperature Controllers
- Temperature/Humidity Transducers
- SSRs/Power Controllers
- Counters
- Timers
- Panel Meters
- Tachometer/Pulse (Rate) Meters
- Display Units
- Sensor Controllers

Autonics Corporation
<http://www.autonics.com>

■ HEADQUARTERS:
 18, Bansong-ro 513beon-gil, Haeundae-gu, Busan, South Korea, 48002
 TEL: 82-51-519-3232
 E-mail: sales@autonics.com

DRW180136AC