

Old/New Model Replacement Table

I/O Cable CJ Series is re-named to CH/CO Series.

According to renaming, replacement of model name from CJ Series to CH/CO Series is followings.

If there is no item you are looking for, please contact Autonics.

Connector type cable

| Connector type | Old model name | New model name | |
|---------------------|---------------------|---------------------|-------------------|
| PLC | Hirose 20-pin plug | CJ-HPHP20-V1N□-1ANL | CH20-HP□-1L |
| | | CJ-HPHP20-V1N□-1ANR | CH20-HP□-1R |
| | | CJ-HPHP20-V1N□-2ANR | CH20-HP□-4R |
| | | CJ-HPHP20-V1N□-1BNR | CH20-HP□-A4T3R |
| | | CJ-HPHP20-V1N□-1APR | CH20-HP□-C1T1R |
| | | CJ-HPHP20-V1N□-1CNL | CH20-HP□-D1T1L |
| | CJ-HPHP20-V1N□-1CNR | CH20-HP□-D1T1R | |
| | Hirose 40-pin plug | CJ-HPHP40-V1N□-1ANL | CH40-HP□-1L |
| | | CJ-HPHP40-V1N□-6ANL | CH40-HP□-8L |
| | | CJ-HPHP40-VF2□-2ANL | CH40-HP□-8L-FS |
| | | CJ-HPHP40-VF2□-2ANR | CH40-HP□-8R-FS |
| | | CJ-HPHP40-VF2□-2ANX | CH40-HP□-8X-FS |
| | | CJ-HPHP40-VF2□-2ANY | CH40-HP□-8Y-FS |
| | | CJ-HPHP40-VY2□-2ANL | CH40-HP□-8L-YS |
| | | CJ-HPHP40-VY2□-2ANR | CH40-HP□-8R-YS |
| | | CJ-HPHP40-VY2□-2ANX | CH40-HP□-8X-YS |
| | | CJ-HPHP40-VY2□-2ANY | CH40-HP□-8Y-YS |
| | | CJ-HPHP40-V2■□-1ANL | CH40-HP□-E1T1L-2■ |
| | | CJ-HPHP40-V1N□-1BNL | CH40-HP□-E1T3L |
| | | CJ-HPHP40-V1N□-1APL | CH40-HP□-E1T4L |
| | | CJ-HPHP40-V2■□-1APL | CH40-HP□-E1T4L-2■ |
| | Fujitsu 40-pin plug | CJ-HPFP40-V1N□-1ANR | CH40-FP□-1R |
| | | CJ-HPFP40-V1N□-2ANL | CH40-FP□-4L |
| | | CJ-HPFP40-V1N□-2ANR | CH40-FP□-4R |
| | | CJ-HPFP40-V2■□-1CNL | CH40-FP□-D7T1L-2■ |
| | | CJ-HPFP40-V2■□-1CNR | CH40-FP□-D7T1R-2■ |
| | | CJ-HPFP40-V2■□-1ANR | CH40-FP□-E1T1R-2■ |
| | | CJ-HPFP40-V1N□-1BNR | CH40-FP□-E1T3R |
| | | CJ-HPFP40-V1N□-1APR | CH40-FP□-E1T4R |
| | | CJ-HPFP40-V2■□-1APR | CH40-FP□-E1T4R-2■ |
| | | CJ-HPFP40-V1N□-1CPL | CH40-FP□-E5D4L |
| | | CJ-HPFP40-V1N□-1CNL | CH40-FP□-E5E1L |
| | | CJ-HPFP40-V1N□-1CNR | CH40-FP□-E5E1R |
| | | CJ-HPFP40-V1N□-3BNL | CH40-FP□-E5T3L |
| | | CJ-HPFP40-V1N□-3BNR | CH40-FP□-E5T3R |
| | D-Sub 37-pin plug | CJ-HPDP37-V1N□-1ANL | CH37-DP□-2L |
| CJ-HPDP37-V1N□-1ANR | | CH37-DP□-3R | |
| CJ-HPDP37-V1N□-1CPR | | CH37-DP□-B6T1R | |
| CJ-HPDP37-V1N□-1CNR | | CH37-DP□-B6T4R | |
| CJ-HPDP37-V2■□-1CPR | | CH37-DP□-B8T1R-2■ | |
| CJ-HPDP37-V2■□-1CPL | | CH37-DP□-F9T4L-2■ | |
| CJ-HPDP37-V1N□-1CNL | | CH37-DP□-J7T1L | |
| CJ-HPDP37-V1N□-1CPL | | CH37-DP□-J7T4L | |
| D-Sub 37-pin socket | | CJ-HPDS37-V1N□-1ANR | CH37-DS□-4R |
| | | CJ-HPDS37-V1N□-1CNR | CH37-DS□-J5T1R |
| | CJ-HPDS37-V1N□-1BNR | CH37-DS□-J5T3R | |
| | CJ-HPDS37-V1N□-1CPR | CH37-DS□-J5T4R | |
| | CJ-HPDS37-V2■□-1CNR | CH37-DS□-J7T1R-2■ | |
| | CJ-HPDS37-V2■□-1CPR | CH37-DS□-J7T4R-2■ | |
| SERVO | 3M 20-pin plug | CJ-HPMP20-H1N□-1ANR | CH20-MP□-8R |
| | | CJ-HPMP20-H1N□-3ANR | CH20-MP□-MR |
| | 3M 50-pin plug | CJ-HPMP50-H1N□-1ANR | CH50-MP□-8R |
| | | CJ-HPMQ50-H1N□-1ANR | CH50-MQ□-8R |

Open type cable

| Connector type | Old model name | New model name | |
|---------------------|---------------------|----------------|------------|
| PLC | Hirose 20-pin plug | CJ-HP20-VP□-L | CO20-HP□-L |
| | | CJ-HP20-VP□-R | CO20-HP□-R |
| | Hirose 40-pin plug | CJ-HP40-VP□-L | CO40-HP□-L |
| | Fujitsu 40-pin plug | CJ-FP40-VP□-L | CO40-FP□-L |
| | | CJ-FP40-VP□-R | CO40-FP□-R |
| | D-Sub 37-pin plug | CJ-DP37-VP□-L | CO37-DP□-L |
| CJ-DP37-VP□-R | | CO37-DP□-R | |
| D-Sub 37-pin socket | CJ-DS37-VP□-R | CO37-DS□-R | |
| SERVO | Hirose 50-pinplug | CJ-HP50-HP□-R | CO50-HP□-R |
| | 3M 20-pin plug | CJ-MP20-HP□-R | CO20-MP□-R |
| | 3M 50-pin plug | CJ-MP50-HP□-R | CO50-MP□-R |

New connector type cable

| Connector type | New model name | | |
|---------------------|---------------------|--------------------|-------------|
| PLC | Hirose 20-pin plug | CH20-HP□-4L | |
| | | CH20-HP□-A4T1L | |
| | | CH20-HP□-A4T2L | |
| | | CH20-HP□-A4T4L | |
| | | CH20-HP□-A4T5L | |
| | | CH20-HP□-C1T2R | |
| | | CH20-HP□-C1T4R | |
| | | CH20-HP□-C1T5R | |
| | | CH20-HP□-D1T3R | |
| | | CH20-HP□-D1T6R | |
| | | CH20-HP□-D4T1R | |
| | | CH20-HP□-D4T7R | |
| | | Hirose 40-pin plug | CH40-HP□-1R |
| | | | CH40-HP□-4L |
| | CH40-HP□-D1T1R | | |
| | CH40-HP□-E1T1L | | |
| | CH40-HP□-E1T2L | | |
| | CH40-HP□-F5T1L | | |
| | CH40-HP□-F5T2L | | |
| | CH40-HP□-F5T3L | | |
| | CH40-HP□-HCM2L | | |
| | CH40-HP□-HCM3L | | |
| | CH40-HP□-ICM1L | | |
| | CH40-HP□-ICM2L | | |
| | CH40-HP□-ICM4L | | |
| | CH40-HP□-ICM5L | | |
| | Fujitsu 40-pin plug | CH40-HP□-L9M1R | |
| | | CH40-HP□-L9M3R | |
| CH40-HP□-L9M4R | | | |
| CH40-HP□-L9M6R | | | |
| CH40-FP□-E1T1R | | | |
| CH40-FP□-E1T2R | | | |
| CH40-FP□-E1T6R | | | |
| CH40-FP□-I4M1R | | | |
| CH40-FP□-I4M4R | | | |
| CH40-FP□-I4T1R | | | |
| CH40-FP□-L1T4L | | | |
| D-Sub 37-pin plug | CH40-FP□-W4T2R | | |
| | CH40-FP□-W4T5R | | |
| | CH40-FP□-X1T3L | | |
| | CH40-FP□-X1T6L | | |
| D-Sub 37-pin socket | CH37-DP□-B6T2R | | |
| | CH37-DP□-B6T5R | | |
| | CH37-DS□-F5T1R | | |
| | CH37-DS□-F5T4R | | |

※□: Cable length
■: Cable branching type

- IO Terminal Blocks
- Interface Terminal Blocks
- Common Terminal Blocks
- Sensor Connector Terminal Blocks
- Relay Terminal Blocks
- I/O Cables
- Connector Type Cables
- Open Type Cables
- Old/New Model Replacement Table
- Remote I/O
- Others