

Small And Amplifier Built-in Type

Small Emitter/Receiver Synchronizing Type

Features

- Small size: W12×H16×D30mm
- Minimize malfunction by extraneous light by synchronizing emitter and receiver
- Reverse power polarity and overcurrent protection circuit
- Fast response speed: Max. 1ms





Specifications

Model		Standard type	Side sensing type	
		BY500-TDT	BYS500-TDT	
Sensing type		Through-beam		
Sensing distance		500mm		
Sensing target		Opaque materials of min. Ø5mm		
Response time		Max. 1ms		
Power supply		12-24VDC ±10% (Ripple P-P: Max. 10%)		
Current consumption		Max. 30mA		
Light source		Infrared LED (940nm)		
Operation mode		Dark ON		
Control output		NPN open collector output ■ Load voltage: 30VDC ■ Load current: Max. 100mA ■ Residual voltage: Max. 1V		
Protection circuit		Reverse polarity protection, output short-circuit protection		
Indicator		Operation indicator: red LED		
Insulation resistance		Min. 20MΩ (at 500VDC megger)		
Noise resistance		±240V the square wave noise (pulse width: 1μs) by the noise simulator		
Dielectric strength		1,000VAC 50/60Hz for 1minute		
Vibration		1.5mm amplitude at frequency of 10 to 55Hz (for 1 min.) in each X, Y, Z direction for 2 hours		
Shock		500m/s² (approx. 50G) in each X, Y, Z direction for 3 times		
Environ- ment	Ambient illumination	Sunlight: Max. 11,0001x Incandescent lamp: Max. 3,000 lx (Receiving illumination)		
	Ambient temperature	-10 to 60°C, storage: -25 to 70°C		
	Ambient humidity	35 to 85%RH, storage: 35 to 85%RH		
Protection structure		IP50 (IEC standard)		
Material		Case: ABS, Sensing part: Acrylic		
Cable		Ø4mm, 4-wire, Length: 2m (Emitter of through-beam type: Ø4mm, 3-wire, Length: 2m) (AWG22, Core diameter: 0.08mm, Number of cores: 60, Insulator out diameter: Ø1.25mm)		
Accessories		Mounting bracket, Bolts/Nuts		
Unit weight		Approx. 150g		

XThe temperature or humidity mentioned in Environment indicates a non freezing or condensation environment.

(A) Photoelectri

(B) Fiber Optic

> (C) Door/Area Sensors

(D) Proximity Sensors

(E) Pressure Sensors

(F) Rotary Encoders

(G) Connectors/ Sockets

(H) Temperature Controllers

(I) SSRs / Power Controllers

(J) Counters

()

L) anel leters

(M) Tacho / Speed / Pulse Meters

(N) Display Units

> O) ensor ontrollers

(P) Switching Mode Power Supplies

(Q) Stepper Motors & Drivers & Controllers

(R) Graphic/ Logic Panels


(S) Field Network Devices


(T) Software

A-33


Autonics

Feature Data






■ Control Output Diagram




Operation Mode



- If the control output terminal is short-circuited or overcurrent condition exists, the control output turns OFF due to
 protection circuit.
- XPlease supply the power to the brown and the blue wires of the emitter and Synchronous wire (white) of the receiver must be connected with that of the emitter.

Connections



- XThe power of the emitter and the receiver must be supplied from the same power line.
- **Synchronous wire (white) of the receiver must be connected with that of the emitter, or it may cause malfunction.


A-34 Autonics

Small And Amplifier Built-in Type

M3 Bolt

■ Dimensions (unit: mm)






• BYS500-TDT


16

5



24


32



12


M3.5 Bolt


Optical axis



■ Mounting And Sensitivity Adjustment

- 1. Supply the power to the sensor, after installing the emitter and the receiver facing each other.
- Set the receiver in the middle of position where the operation indicator turns ON adjusting the receiver to the right and the left or up and down.
- 3. Fix both units tightly after checking that the unit detects the target.
- ※If a sensing target is translucent body or smaller than Ø5mm, it might not be detected because the because light penetrate it.





(A) Photoelectric Sensors

(B) Fiber Optic

> (C) Door/Area Sensors

(D) Proximity Sensors

(E) Pressure

(F) Rotary Encoders

Encoders

Sockets

(H) Temperature Controllers

(I) SSRs / Power Controllers

(J) Counters

(K)

(L) Panel

(M) Tacho / Speed / Pulse

splay

O) Sensor

(P)

(P) Switching Mode Power Supplies

(Q) Stepper Motors & Drivers & Controllers

(R) Graphic/ Logic Panels

(S) Field Network Devices

> (T) Software

Autonics A-35